

Apter Power CC-TAIX11

Installation, Application and Verification Guide

A field guide for planning, installing and verifying the Honeywell CC-TAIX11 redundant Series-C analog-input IOTA.

1. Product identity and application

Product role	Series-C analog-input IOTA
Configuration	Redundant termination assembly
Input context	High-level current or voltage analog inputs
Service focus	Module pairing, field wiring and redundancy verification

2. Pre-installation review

- Confirm CC-TAIX11 and the complete spare-part marking.
- Verify the installed redundant arrangement and compatible Series-C input modules.
- Review channel type, transmitter power, input range and field wiring.
- Record primary and secondary module status and the active diagnostic condition.
- Apply isolation, process-safety and ESD controls before field work.

Important

Use the exact installed-system documentation and the applicable Honeywell instructions. Do not transfer wiring, configuration or ratings from a similar model.

3. Installation and application workflow

1	Record IOTA position, redundant module pairing, channel use and terminal identification.
2	Inspect carrier engagement, connectors, terminal plugs and field-wire condition.
3	Install CC-TAIX11 in the documented carrier location and secure all hardware.
4	Reconnect each input channel, transmitter supply, shield and return per the drawing.
5	Restore the system and verify redundancy status, diagnostics and analog measurement response.

4. Commissioning and verification record

Check	Acceptance point	Record
Identity	CC-TAIX11 and the redundant module pair match the approved design.	Pass / Review
Mechanical	Carrier, connectors and terminal hardware are secure.	Pass / Review
Electrical	Input wiring, transmitter power, shielding and grounding are correct.	Pass / Review
Redundancy	Primary/secondary status and switchover indications are accepted.	Pass / Review
Functional	Analog values, diagnostics, alarms and control use are verified.	Pass / Review

Record equipment identity, technician, date, control-system status and any corrective action in the site maintenance system before closing the work order.

5. Product-specific precautions

1

Do not replace CC-TAIX11 with a non-redundant IOTA without an approved design change.

2

Confirm compatible analog-input module types before installation.

3

Preserve transmitter power and return connections when recording the installed wiring.

4

Protect connectors, terminals and printed-circuit surfaces from ESD and contamination.

5

Do not copy range or channel settings from a different transmitter service.

6

Verify redundancy health before placing the affected channels back in service.

7

Check loop indication, diagnostics and alarms after commissioning.

8

Record final wiring, module status and any configuration changes.

6. Official manufacturer sources

Honeywell Series-C I/O User's Guide	prod-edam.honeywell.com
Honeywell Experion Series-C I/O Specification	prod-edam.honeywell.com

Prepared by Apter Power for product identification, installation planning and verification. Always use the current project documentation and the applicable Honeywell instructions for the installed system.

APTER POWER SALES TEAM

INDUSTRIAL AUTOMATION PRODUCT SUPPORT

One verified model, one engineered configuration path.

WHATSAPP / PHONE

+86 180 3023 5313

EMAIL

sales13@apterpower.com

WEBSITE

www.apterpower.com



SCAN FOR PRODUCT & QUOTE

CC-TAIX11