

Apter Power CC-TAOX11

Installation, Application and Verification Guide

A field guide for planning, installing and verifying the Honeywell CC-TAOX11 redundant Series-C analog-output IOTA.

1. Product identity and application

Product role	Series-C analog-output IOTA
Configuration	Redundant termination assembly
Supported context	Series-C analog-output module arrangements
Service focus	Output wiring, redundancy and commissioning checks

2. Pre-installation review

- Confirm CC-TAOX11 and the complete spare-part marking.
- Verify the compatible analog-output module pair and redundant carrier arrangement.
- Review output-loop wiring, load, grounding, channel assignment and safe-state configuration.
- Record primary and secondary module status and the current output conditions.
- Apply process isolation, lockout and ESD controls before field work.

Important

Use the exact installed-system documentation and the applicable Honeywell instructions. Do not transfer wiring, configuration or ratings from a similar model.

3. Installation and application workflow

1	Record IOTA position, redundant module pairing, loop use and terminal identification.
2	Inspect carrier engagement, connectors, terminal plugs and field wiring.
3	Install CC-TAOX11 in the specified carrier location and secure the hardware.
4	Reconnect output loops, returns, shields and grounding exactly as documented.
5	Restore service and verify redundancy status, output response, diagnostics and alarms.

4. Commissioning and verification record

Check	Acceptance point	Record
Identity	CC-TAOX11 and its redundant module pair match project records.	Pass / Review
Mechanical	Carrier, terminal hardware and connectors are secure.	Pass / Review
Electrical	Output wiring, load, shielding, grounding and polarity are correct.	Pass / Review
Redundancy	Primary/secondary status and approved transfer behavior are verified.	Pass / Review
Functional	Output response, readback, diagnostics and process indication are accepted.	Pass / Review

Record equipment identity, technician, date, control-system status and any corrective action in the site maintenance system before closing the work order.

5. Product-specific precautions

1

Do not substitute a non-redundant IOTA without an approved engineering change.

2

Confirm the exact analog-output module type paired with CC-TAOX11.

3

Record safe-state and channel configuration before disconnecting the installed assembly.

4

Protect carrier connectors and terminal interfaces from ESD and contamination.

5

Verify output-loop polarity, load and grounding before energizing.

6

Do not transfer configuration from an unrelated analog-output service.

7

Commission affected output loops using the approved process-isolation procedure.

8

Record final redundancy status, diagnostics and output checks.

6. Official manufacturer sources

[Honeywell Series-C I/O User's Guide](#)

prod-edam.honeywell.com

[Honeywell Experion Series-C I/O Specification](#)

prod-edam.honeywell.com

Prepared by Apter Power for product identification, installation planning and verification. Always use the current project documentation and the applicable Honeywell instructions for the installed system.

APTER POWER SALES TEAM

INDUSTRIAL AUTOMATION PRODUCT SUPPORT

One verified model, one engineered configuration path.

WHATSAPP / PHONE

+86 180 3023 5313

EMAIL

sales13@apterpower.com

WEBSITE

www.apterpower.com



SCAN FOR PRODUCT & QUOTE

CC-TAOX11