

MANUFACTURER-SOURCE TECHNICAL REFERENCE

# ABB INIIT12

## INIIT12 Evidence-Bounded Product Information Manual

ABB INIIT12 remote transfer module

### DOCUMENT SCOPE

Independent Apter Power manual compiled only from the cited ABB manufacturer sources. No product photograph is included.

|                           |                                                                   |
|---------------------------|-------------------------------------------------------------------|
| Product / lookup identity | ABB INIIT12                                                       |
| Reference number          | INIIT12                                                           |
| Document basis            | Published ABB product records, PDFs, and manuals listed on page 3 |



### Product page

<https://www.apterpower.com/ABB/iniit12>

### Apter Power contact

[sales13@apterpower.com](mailto:sales13@apterpower.com) | +86 180 3023 5313

## Workflow and system context

ABB INIIT12 is an evidence-bounded remote transfer module in the Bailey INFI 90 / Harmony Rack installed-base context. System role: It provides bidirectional Cnet/INFI-NET remote transfer through two RS-232-C ports located on NTMP01.

- |    |                                                                                                                      |
|----|----------------------------------------------------------------------------------------------------------------------|
| 01 | System Inputs: It provides bidirectional Cnet/INFI-NET remote transfer through two RS-232-C ports located on NTMP01. |
| 02 | Processing: The module occupies one MMU slot, interfaces to Controlway and connects by cable to NTMP01.              |

## Published context and boundaries

- |    |                                                                                                                          |
|----|--------------------------------------------------------------------------------------------------------------------------|
| 01 | Verify the complete ABB INIIT12 nameplate, revision and installed-system documentation before use.                       |
| 02 | Keep INIIT12 distinct from INIIT13, SPIIT12 and local-transfer models; verify installed INNIS and termination revision.  |
| 03 | Current formal lifecycle phase, origin, HS code, dimensions and logistics weight remain HOLD without exact ABB evidence. |

## Verification and release checks

|    |                                                                                                                                |
|----|--------------------------------------------------------------------------------------------------------------------------------|
| 01 | Verify the complete ABB INIIT12 nameplate, revision and installed-system documentation before use.                             |
| 02 | Keep INIIT12 distinct from INIIT13, SPIIT12 and local-transfer models; verify installed INNIS and termination revision.        |
| 03 | De-energize and follow the site's approved electrical and process-safety procedure before disturbing hardware or field wiring. |
| 04 | Back up controller, network, I/O, addressing and configuration data before replacement or firmware work.                       |
| 05 | Verify every companion module, termination unit, cable, connector and power source from approved drawings.                     |
| 06 | Do not copy electrical, communication, mechanical or lifecycle values from a related model or successor.                       |

## Identity and release controls

|                     |                               |
|---------------------|-------------------------------|
| Verification Status | Verified Exact Model Function |
|---------------------|-------------------------------|

### Official ABB sources

|                                                          |                                                                                                                                                                                                                                                                                                                           |
|----------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| ABB Harmony Rack Communications Coupler Product Overview | <a href="https://library.e.abb.com/public/064d6092d27323a7c1256e40007d6dbd/WBPPEUS250002C1-waste_-_en_Harmony_Rack_Communications_Coupler_Product_Overview.pdf">https://library.e.abb.com/public/064d6092d27323a7c1256e40007d6dbd/WBPPEUS250002C1-waste_-_en_Harmony_Rack_Communications_Coupler_Product_Overview.pdf</a> |
|----------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|