

MANUFACTURER-SOURCE TECHNICAL REFERENCE

Allen-Bradley 1336-PB-SP5A

1336-PB-SP5A Evidence-Bounded Product Information Manual

Rockwell Automation 1336 precharge printed-circuit board

DOCUMENT SCOPE

Independent Apter Power manual compiled only from the cited Rockwell Automation manufacturer sources. No product photograph is included.

Product / lookup identity	Allen-Bradley 1336-PB-SP5A
Reference number	1336-PB-SP5A
Document basis	Published Rockwell Automation product records, PDFs, and manuals listed on page 3



Product page

<https://www.apterpower.com/Allen-Bradley/1336-pb-sp5a>

Apter Power contact

sales13@apterpower.com | +86 180 3023 5313

Workflow and system context

Allen-Bradley 1336-PB-SP5A is an evidence-bounded 1336 precharge printed-circuit board. System role: It is a precharge circuit-board spare part for the exact 1336 drive frames and voltage class listed in the official parts table.

- | | |
|----|---|
| 01 | System Inputs: It is a precharge circuit-board spare part for the exact 1336 drive frames and voltage class listed in the official parts table. |
| 02 | Processing: Match the complete drive catalog, voltage class, horsepower range, frame and board revision before replacement. |

Published context and boundaries

- | | |
|----|--|
| 01 | Verify the complete Allen-Bradley 1336-PB-SP5A physical label and installed-system documentation before use. |
| 02 | Do not transfer specifications or interchangeability from SP21B, SP22C, other 1336 precharge boards or similarly named power boards. |
| 03 | Origin and HS code remain unpublished unless an exact manufacturer record or the physical package label establishes them. |

Verification and release checks

01	Verify the complete Allen-Bradley 1336-PB-SP5A label, revision and installed-system documentation before use.
02	Do not transfer specifications or interchangeability from SP21B, SP22C, other 1336 precharge boards or similarly named power boards.
03	De-energize the equipment and follow the site's approved electrical and process-safety procedure before disturbing hardware or wiring.
04	Back up controller, drive, network and configuration data before replacement, migration or firmware work.
05	Verify every companion module, cable, connector, termination and power source from approved drawings.
06	Do not copy electrical, communication, mechanical or lifecycle values from a related model or successor.

Identity and release controls

Verification Status	Verified Exact Catalog Number
---------------------	-------------------------------

Official Rockwell Automation sources

1336 Parts List	https://literature.rockwellautomation.com/idc/groups/literature/documents/pa/1336-pa001_-en-p.pdf
-----------------	---