

MANUFACTURER-SOURCE TECHNICAL REFERENCE

Honeywell 10001/A/1

10001/A/1 Product Information Manual

wiring part for the FSC vertical bus driver

DOCUMENT SCOPE

Independent Apter Power manual limited to verified identity evidence and any directly relevant Honeywell sources listed in this document. No product photograph is included.

Product / lookup identity	Honeywell 10001/A/1
Reference number	10001/A/1
Document basis	Published Honeywell product records, PDFs, and manuals listed on page 3



Product page

<https://www.apterpower.com/Honeywell/10001-a-1>
Apter Power contact

sales13@apterpower.com | +86 180 3023 5313

Workflow and system context

Honeywell 10001/A/1 is the wiring part used with 10001/1/1 and 10001/R/1 FSC vertical bus drivers. Use 10001/A/1 only with the exact host, rack or chassis, terminal hardware, cable and project configuration specified for the installed system.

- | | |
|----|---|
| 01 | System Inputs: wiring part for the FSC vertical bus driver |
| 02 | Processing: Use 10001/A/1 only with the exact host, rack or chassis, terminal hardware, cable and project configuration specified for the installed system. |

Published context and boundaries

- | | |
|----|---|
| 01 | Use 10001/A/1 only with the exact host, rack or chassis, terminal hardware, cable and project configuration specified for the installed system. |
| 02 | Lifecycle evidence boundary: Use the cited model-level lifecycle statement where supplied. |
| 03 | Verify the complete Honeywell 10001/A/1 physical label before use. |

Verification and release checks

01	Verify the complete Honeywell 10001/A/1 physical label before use.
02	Use 10001/A/1 only with the exact host, rack or chassis, terminal hardware, cable and project configuration specified for the installed system.
03	Confirm the exact rack or chassis position, terminal assembly, cable, connector, power and project revision.
04	De-energize the equipment unless the exact hardware manual and site procedure explicitly permit energized service.
05	Back up controller, communication and I/O configuration before replacement or migration work.
06	Do not transfer electrical, communication or mechanical values from a related model or different suffix.

Identity and release controls

Verification Status	Verified Product Reference
---------------------	----------------------------