

MANUFACTURER-SOURCE TECHNICAL REFERENCE

Honeywell 942-M0A-2D-1G1-220S

942-M0A-2D-1G1-220S Product Information Manual

Series 942 ultrasonic sensor control amplifier

DOCUMENT SCOPE

Independent Apter Power manual limited to verified identity evidence and any directly relevant Honeywell sources listed in this document. No product photograph is included.

Product / lookup identity	Honeywell 942-M0A-2D-1G1-220S
Reference number	942-M0A-2D-1G1-220S
Document basis	Published Honeywell product records, PDFs, and manuals listed on page 3



Product page

<https://www.apterpower.com/Honeywell/942-m0a-2d-1g1-220s>
Apter Power contact

sales13@apterpower.com | +86 180 3023 5313

Workflow and system context

Honeywell 942-M0A-2D-IG1-220S is a Series 942 ultrasonic sensor control amplifier with analog, switching and digital outputs. Use 942-M0A-2D-IG1-220S only with the exact host, rack or chassis, terminal hardware, cable and project configuration specified for the installed system.

- 01System Inputs: Series 942 ultrasonic sensor control amplifier
- 02Processing: Use 942-M0A-2D-IG1-220S only with the exact host, rack or chassis, terminal hardware, cable and project configuration specified for the installed system.

Published context and boundaries

- 01Use 942-M0A-2D-IG1-220S only with the exact host, rack or chassis, terminal hardware, cable and project configuration specified for the installed system.
- 02Lifecycle evidence boundary: Use the cited model-level lifecycle statement where supplied.
- 03Verify the complete Honeywell 942-M0A-2D-IG1-220S physical label before use.



Verification and release checks

01	Verify the complete Honeywell 942-M0A-2D-IG1-220S physical label before use.
02	Use 942-M0A-2D-IG1-220S only with the exact host, rack or chassis, terminal hardware, cable and project configuration specified for the installed system.
03	Confirm the exact rack or chassis position, terminal assembly, cable, connector, power and project revision.
04	De-energize the equipment unless the exact hardware manual and site procedure explicitly permit energized service.
05	Back up controller, communication and I/O configuration before replacement or migration work.
06	Do not transfer electrical, communication or mechanical values from a related model or different suffix.

Identity and release controls

Verification Status	Verified Product Reference
---------------------	----------------------------