

IMFEC11 field workflow

Identity, safe replacement and controlled acceptance

01 / Establish exact identity

Confirm the complete model, article identity where present, product family and recorded installed-system position.

02 / Capture the as-found state

The termination-device choice defines supported signals and loop power. Do not transfer wiring between NTBMC2 and NTBMD2 without checking the documented channel and power arrangement.

03 / Control the process

Place all affected analog loops and process functions in the approved maintenance state.

04 / Prove the restored function

Release the module only after every assigned channel passes engineering acceptance.

Before removal

Eight exact-model checks that form the maintenance hold point

CHECK 1	Confirm the exact IMFEC11 identity and its recorded Harmony rack position.
CHECK 2	Place all affected analog loops and process functions in the approved maintenance state.
CHECK 3	Record the termination device as NTBMC2 or NTBMD2 before disturbing field wiring.
CHECK 4	Preserve all fifteen channel assignments, signal ranges and loop-power sources.
CHECK 5	Do not treat a system-powered NTBMC2 loop as equivalent to a field-powered NTBMD2 circuit.
CHECK 6	Retain the documented I/O expander-bus address and companion-module arrangement.
CHECK 7	Check current, voltage or FSK behavior with controlled signals after restoration.
CHECK 8	Release the module only after every assigned channel passes engineering acceptance.

Installation sequence

Restore the documented hardware, wiring and configuration boundaries

1. Inspect identity and condition

Check the exact model marking, connectors, terminals and service condition before the component enters the controlled installation area.

2. Match the installed position

Use the recorded rack, node, channel or machine position; do not infer suitability from a similar front label.

3. Restore field connections

Do not treat a system-powered NTBMC2 loop as equivalent to a field-powered NTBMD2 circuit.

4. Restore configuration

Retain the documented I/O expander-bus address and companion-module arrangement.

5. Re-energize under control

Apply the approved plant sequence and compare initial module indications with the captured as-found record.

Commissioning and acceptance

Tests must follow the actual channel map and controlled process state

Identity	Installed model and article identity match the maintenance record.
Connections	All documented terminals, connectors and companion devices are restored.
Configuration	Recorded settings, ranges, filters or addresses are restored without borrowing nearby values.
Diagnostics	Module indication and controller diagnostics agree with the controlled test state.
Channel proof	Check current, voltage or FSK behavior with controlled signals after restoration.
Process proof	Release the module only after every assigned channel passes engineering acceptance.
Documentation	Final identity, test results and acceptance authority are retained with the work record.
Release	The affected system returns to service only after the approved acceptance hold point.

Service record and support

Manufacturer sources, verified related pages and direct contact

MANUFACTURER EVIDENCE BASIS

- ABB IMFEC11 product page
- ABB Harmony Rack I/O product overview
- ABB Harmony termination-device data sheet

External manufacturer URLs are intentionally omitted from this document.

VERIFIED RELATED ABB PRODUCT PAGES

01	ABB BC810K01 3BSE031154R1 Open verified ApterPower page
02	ABB TB811 3BSE008568R1 Open verified ApterPower page
03	ABB CI857K01 3BSE018144R1 Open verified ApterPower page
04	ABB PM866K01 3BSE050198R1 Open verified ApterPower page
05	ABB CI854AK01 3BSE030220R1 Open verified ApterPower page
06	ABB CI830 3BSE013252R1 Open verified ApterPower page
07	ABB CI840A 3BSE041882R1 Open verified ApterPower page
08	ABB CI801 3BSE022366R1 Open verified ApterPower page

APTER POWER SALES TEAM

WHATSAPP / PHONE +86 180 3023 5313

EMAIL sales13@apterpower.com

WEBSITE www.apterpower.com



IMFEC11