

Siemens 505-4632

Installation & Commissioning Guide

Siemens 505-4632 is a single-wide SIMATIC 505 module with 32 non-latching AC outputs for 24 to 115 V AC field loads.

PRODUCT ROLE AND VERIFIED FEATURES

Feature 1

Provides 32 AC output channels.

Feature 2

Operates across 20 to 132 V AC at 47 to 63 Hz.

Feature 3

Uses an R-C surge suppressor on the output circuits.


Feature 4

Uses a single-wide module format.

VERIFIED DATA SNAPSHOT

Output channels	32
Rated load supply	24 to 115 V AC
Operating range	20 to 132 V AC
Frequency	47 to 63 Hz

SYSTEM RELATIONSHIP



APTERPOWER SALES TEAM
 WhatsApp / Phone: +86 180 3023 5313
 Email: sales13@apterpower.com
 Scan the approved WhatsApp code for model-specific support.



Pre-installation readiness

READINESS GATE

Identity Compare the complete marking with the approved work order and installed record.	System match Confirm the receiving channel, mating components and controlled configuration.
Physical condition Inspect mounting surfaces, connectors, terminals, cable and support hardware.	Work controls Apply authorized isolation, bypass, access and restoration procedures.

TECHNICAL PROFILE FOR THE WORK

Output channels 32	Rated load supply 24 to 115 V AC
Operating range 20 to 132 V AC	Frequency 47 to 63 Hz
Minimum load 5 mA	Overload 5 A RMS for two cycles
ON-state drop 1.8 V at 0.5 A	Surge protection R-C suppressor
Output behavior Non-latching, unprotected	Module format Single-wide

IMPORTANT NOTICE

Resolve every unmatched interface, configuration or receiving-system condition before removal or installation.

SOURCE AND WORK CONTROLS

Manufacturer source	SIMATIC 505 Input/Output Modules User Manual, order number 505-8105-2
Evidence boundary	Technical statements are limited to the identified product or applicable manufacturer family.
Selection control	Use the complete ordering string and verify the installed system before purchase or installation.

Installation sequence

CONTROLLED WORK STEPS

- 01 Verify every connected load is compatible with the documented AC range.
- 02 Isolate rack and external load power before handling conductors.
- 03 Record channel, common and branch-protection assignments before removal.
- 04 Review steady-state and inrush current for each controlled load.
- 05 Retain the approved fuse and upstream protective-device coordination.
- 06 Separate AC output wiring from low-level signal wiring.
- 07 Check for unintended leakage-driven operation before enabling the process.
- 08 Command each point and verify the field load and PLC indication agree.

CONNECTION RECORD

As found	Photograph and label every connection and installed orientation before removal.
Mechanical	Record mounting position, support, clearance and connector engagement.
Electrical	Record polarity, common, shield, channel assignment and cable route.
Configuration	Preserve approved settings, scaling, alarm logic and acceptance limits.
As left	Record the final physical condition and any controlled deviation.



WORK HOLD POINTS

Before removal	Identity, position, wiring, orientation and controlled settings recorded.
Before connection	Mating interfaces, condition and routing reviewed.
Before power-up	Mechanical work, wiring, shielding and configuration independently checked.
Before release	Static value, dynamic response and protection behavior accepted.

Commissioning and functional proof

COMMISSIONING SEQUENCE

Initial state Observe status at power-up and check for unexpected fault or alarm indication.	Static value Verify the expected bias, gap, loop, contact or channel value for the application.
Dynamic response Apply the approved machine or test stimulus and confirm response and scaling.	Protection path Verify the configured alarm, relay, data or receiving-system behavior.

APPLICATION-SPECIFIC EVIDENCE

AC contactor control Switch approved AC relay or contactor coils under PLC logic.	Machine auxiliaries Operate lamps, small valves and other compatible AC loads.
Process sequencing Distribute mains-level output commands through the existing point map.	Rack maintenance Retain a 32-channel AC output function in a SIMATIC 505 installation.

ACCEPTANCE RECORD

Identity	Complete marking and final installed position recorded.
Physical inspection	Mounting, connectors, terminals and routing checked.
Channel status	Expected status and configured measurement confirmed.
Functional test	Required output or protection response demonstrated.
Restoration	Bypasses removed and operating state approved.

COMMISSIONING QUESTIONS

How many AC outputs are available on Siemens 505-4632?	It provides 32 AC output channels.
Which voltage range can Siemens 505-4632 switch?	The operating range is 20 to 132 V AC, with a rated range of 24 to 115 V AC.

Release record and technical references

CLOSEOUT QUESTIONS

Which frequency range applies to Siemens 505-4632?	The outputs are specified for 47 to 63 Hz.
What minimum load is specified for Siemens 505-4632?	The minimum load is 5 mA.
Which surge network is used by Siemens 505-4632?	The output circuits use an R-C surge suppressor.
Are Siemens 505-4632 outputs protected against every field fault?	No. The outputs are documented as unprotected, so branch protection and load checks remain necessary.
What should be checked for AC coil loads on Siemens 505-4632?	Confirm steady-state current, inrush current, suppression and the required protective-device coordination.
How is Siemens 505-4632 accepted after installation?	Command every channel and verify the correct field load, indication and interlock behavior.

RELATED MODELS FOR INSTALLATION PLANNING

Siemens 6DS1717-8RR	Installation-planning reference. Review the complete ordering string before selection.
Siemens 6DS1703-8RR	Installation-planning reference. Compare the required interface and system position.
Siemens 6DS1618-8CA	Installation-planning reference. Confirm the execution independently for the intended task.

MANUFACTURER SOURCE AND FINAL CONTROL

Manufacturer source	SIMATIC 505 Input/Output Modules User Manual, order number 505-8105-2
Evidence boundary	Technical statements are limited to the identified product or applicable manufacturer family.
Selection control	Use the complete ordering string and verify the installed system before purchase or installation.

IMPORTANT NOTICE

Release the equipment only after the responsible site authority accepts the recorded result.

APTERPOWER SALES TEAM
 WhatsApp / Phone: +86 180 3023 5313
 Email: sales13@apterpower.com
 Scan the approved WhatsApp code for model-specific support.

