

Siemens 6ES7132-4HB01-0AB0

01 Plan the controlled replacement

Work boundary

Siemens 6ES7132-4HB01-0AB0 switches two field-load circuits from an ET 200S station while keeping the output channels isolated from one another, the backplane bus and the load supply. Test the command bit, relay contact and field load as separate stages. Record the selected response to CPU or master stop with the output acceptance result.

Preparation sequence

01	Confirm the installed marking is 6ES7132-4HB01-0AB0.
02	Record the normal indication, diagnostic state and connected path.
03	Back up the applicable project, program, wiring record or terminal map.
04	Identify every supply, reference, communication and field connection.
05	Place affected machine functions in the approved maintenance state.
06	Define the functional and fault-response tests before removal.

Technical data to retain

Item	Installed requirement
Output type	Relay
Output channels	2
DC load range	24 to 120 V DC
AC load range	24 to 230 V AC
Nominal output current	5 A per channel
Minimum load current	8 mA
Resistive-load switching rate	2 Hz maximum
Inductive-load switching rate	0.5 Hz maximum

Do not copy a nearby configuration

A visually similar product can use different capacity, channel organization, terminal access or communication settings. Use the exact model and recorded machine position.



Siemens 6ES7132-4HB01-0AB0

02 Disconnect, inspect and install

Pre-installation controls

Step	Control
1	Identify both relay channels and their load circuits before disconnection.
2	Confirm each field voltage is within the specified AC or DC range.
3	Size external circuit protection because the outputs are not short-circuit protected.
4	Check inrush and switching duty for the actual load type.
5	Observe the lower switching-frequency limit for inductive loads.
6	Restore the configured substitute-value behavior before energizing.

Connection records

Identity Photograph and label each connection before removal.	Electrical path Record polarity, reference and protective-device arrangement.
Configuration Retain the approved software, card, module or terminal assignment.	Mechanical fit Inspect seating, keying and connector condition without forcing parts.

Inspection before energization

Correct bent contacts, damaged conductors, loose terminals, contamination or incorrect keying before interpreting any response as a product fault.

Applicable interface values

Interface	Value	Check
Output type	Relay	Confirm the installed output type agrees with this exact configuration.
Output channels	2	Confirm the installed output channels agrees with this exact configuration.



Siemens 6ES7132-4HB01-0AB0

03 Configure and verify operation

Functional test sequence

01	Energize only under the approved controlled condition.
02	Confirm the initial status before issuing commands or applying a signal.
03	Test one channel, object, terminal group or network path at a time.
04	Compare the internal indication with the actual field response.
05	Check the intended diagnostic or alarm behavior.
06	Repeat for every affected function before clearing maintenance controls.

Acceptance observations

Test	Action	Expected result
Identity	Confirm Siemens 6ES7132-4HB01-0AB0.	Complete marking matches the selected record.
Power or passive path	Verify the applicable supply or isolated wiring condition.	No polarity, potential or isolation fault is present.
Configuration	Restore the approved project, module pairing or terminal assignment.	Hardware and stored settings agree.
Functional response	Apply a controlled input, command or communication change.	The intended indication and output path respond.
Fault response	Introduce only the approved diagnostic or interruption test.	The configured status and safe response are visible.
Release	Remove test states and compare the final condition with the baseline.	Normal operation is stable and recorded.

Separate the stages

A correct display or status LED does not prove the downstream field path. Likewise, a physical output does not prove that diagnostics, alarms or retained configuration are correct.

Configuration record

Test the command bit, relay contact and field load as separate stages. Record the selected response to CPU or master stop with the output acceptance result.



Siemens 6ES7132-4HB01-0AB0

04 Troubleshoot by technical symptom

Symptom-led checks

Observed condition	Investigation
No expected response	Trace the source, connection and configured destination before replacing hardware.
Wrong value or state	Compare the exact technical selection, channel identity and retained project data.
Intermittent behavior	Inspect seating, terminal security, signal reference and environmental condition.

Questions 1–4

Which load voltages can Siemens 6ES7132-4HB01-0AB0 switch? Its relay contacts are specified for 24–120 V DC loads or 24–230 V AC loads.	How many field circuits does Siemens 6ES7132-4HB01-0AB0 control? It provides two independently addressed relay output channels.
What continuous current is assigned to each Siemens 6ES7132-4HB01-0AB0 output? Each relay channel is rated for 5 A under the specified operating conditions; the minimum load current is 8 mA.	Why is an external protective device needed with Siemens 6ES7132-4HB01-0AB0? The outputs do not include short-circuit protection, so the field circuit needs the correctly coordinated external protection.

Avoid unsupported adjustment

If the result is inconsistent, check identity, interface selection, channel mapping and retained configuration before changing setpoints or editing the project.

Remaining precautions

Check	Requirement
5	Observe the lower switching-frequency limit for inductive loads.
6	Restore the configured substitute-value behavior before energizing.
7	Prove the field load changes state instead of relying only on the green LED.
8	Verify galvanic isolation and safe contact state before release.



Siemens 6ES7132-4HB01-0AB0

05 Return to service and handover

Questions 5–8

How often may Siemens 6ES7132-4HB01-0AB0 switch an inductive load? The specified maximum switching rate for inductive loads is 0.5 Hz, lower than the 2 Hz limit for resistive or lamp loads.	What can Siemens 6ES7132-4HB01-0AB0 do when the CPU or master stops? The configured response can apply a substitute value or retain the last value; the selected behavior must match the machine safety design.
What do the green indicators on Siemens 6ES7132-4HB01-0AB0 show? Each green channel LED indicates the commanded output state; it does not by itself prove that the relay contact or field load changed state.	How should both channels of Siemens 6ES7132-4HB01-0AB0 be commissioned? Command one output at a time, measure the contact and field-load response, verify electrical isolation and protection, then test the configured stop-state behavior.

Release evidence

Test	Action	Expected result
Fault response	Introduce only the approved diagnostic or interruption test.	The configured status and safe response are visible.
Release	Remove test states and compare the final condition with the baseline.	Normal operation is stable and recorded.

Related Siemens products

Siemens 6DS1412-8RR
Siemens 6DS1411-8RR
Siemens 6DS1300-8AB
Siemens 6ES7417-4XT05-0AB0

Handover record

Record the complete model, configuration source, connection map, observed normal state, diagnostic result and the person or procedure that authorized return to service.

