FIELD WORKFLOW

Honeywell MU-TAMT02 51401491-100

Thermocouple FTA

Honeywell MU-TAMT02 51401491-100 is a sixteen-channel Low Level Multiplexer thermocouple FTA with local cold-junction reference and compression terminals.

Release-gate sequence

1. IDENTIFY
2. ISOLATE
3. INSTALL
4. STATIC CHECK
5. FUNCTION TEST
6. ACCEPT

Before work starts

- Confirm the complete Honeywell MU-TAMT02 51401491-100 identity before isolation.
- Record FTA function: Low Level Multiplexer thermocouple input, Part number: 51401491-100, Channels: 16.
- Photograph the cabinet position, connector orientation and all terminal identifiers.
- Capture the active configuration, channel assignments, alarm limits and dependent control functions.
- Place affected process equipment in the approved safe or manual condition.
- Prepare calibrated test equipment appropriate to the documented signal or interface type.

Field record essentials

MODEL ID

Record MU-TAMT02 51401491-100 exactly.

SYSTEM

h

SETTINGS

Preserve the verified installed configuration.

TEST BASIS

Define static and functional acceptance evidence.

Pre-installation verification

CHECK 01

Confirm the complete Honeywell MU-TAMT02 51401491-100 identity before isolation.

CHECK 02

Record FTA function: Low Level Multiplexer thermocouple input, Part number: 51401491-100, Channels: 16.

CHECK 03

Photograph the cabinet position, connector orientation and all terminal identifiers.

CHECK 04

Capture the active configuration, channel assignments, alarm limits and dependent control functions.

CHECK 05

Place affected process equipment in the approved safe or manual condition.

CHECK 06

Prepare calibrated test equipment appropriate to the documented signal or interface type.

Interface inventory

- Sensor side: Sixteen thermocouple input circuits
- Adapter side: MU-TLPA02 power adapter
- Processor side: MU-PLAM02 Low Level Multiplexer IOP
- Cable path: MU-KFTAxx FTA cable and MU-KLAMxx or MU-KLXxxx remote cable

Hold point

Do not continue if the complete model, field-circuit identity, stored settings, protective functions or safe isolation state cannot be verified. Preserve existing wiring records and escalate the exact unresolved item.

Installation sequence

1. Match the replacement label to Honeywell MU-TAMT02 51401491-100 and the approved site bill of material.
2. Review the recorded wiring, channel map and connector orientation before disturbing conductors.
3. Isolate hazardous energy and prove the required electrical condition at the work point.
4. Apply grounded ESD controls while handling the electronic assembly.
5. Label and remove connectors or conductors without changing their established order.
6. Inspect terminals, pins, coating, guides and mounting hardware for damage or contamination.
7. Seat and secure the assembly without forcing connectors; restore wiring to the recorded positions.
8. Re-energize under an approved procedure and review hardware, channel and communication diagnostics.

Commissioning and acceptance

GATE 1

Verify the installed identity remains Honeywell MU-TAMT02 51401491-100 after energization.

GATE 2

Compare all restored channel or interface assignments with the approved engineering record.

GATE 3

Inject or apply a known field condition to each serviced input and compare the controller value with the calibrated source.

GATE 4

Check alarm, diagnostic and fault responses without defeating any required protective function.

GATE 5

Confirm unaffected channels and neighboring assemblies continue to operate normally.

GATE 6

Review connector temperature, unusual odor, noise and visible indicators during the controlled test.

GATE 7

Record calibrated readings, software indications, status events and corrective actions.

GATE 8

Obtain the required operations or engineering acceptance before releasing the equipment.

Fault-response checks

- An unstable or incorrect input requires checks of field power, polarity, shielding, terminal assignment, scaling and channel status.
- Intermittent behavior: inspect terminal torque, connector seating, shielding and vibration exposure.
- Wrong point response: reconcile the physical terminal, channel map and controller database.
- Persistent diagnostic: compare the as-left condition with the captured pre-maintenance baseline.
- Neighboring faults: inspect shared power, common connectors and card-file or backplane interfaces.
- Repeat failure: stop substitution and escalate the exact identity, evidence and test record for engineering review.

Acceptance boundary

Release only after the normal state, commanded state, principal fault state and recovery behavior have all been observed at the field device, module and control-system indication.

Reference and handover

SOURCE 1

Honeywell HPM High-Performance Process Manager Service, R690, September 2021, pages 68, 145 and 482

SOURCE 2

Honeywell Experion Control Hardware Planning Guide, R301.1, November 2006, pages 191 and 476

Related products

Verified related products on ApterPower

Honeywell FS-TSFIRE-1624
Safety-system termination reference
View Honeywell FS-TSFIRE-1624

Honeywell TA3840C
Honeywell control reference
View Honeywell TA3840C

Honeywell 51306975-175
Honeywell output termination reference
View Honeywell 51306975-175

CONFIGURATION
Final settings and mappings archived

WIRING
Terminal and conductor labels reconciled

TEST RECORD
Measured results and fault tests retained

OPERATIONS
Normal indication and response briefed

Contact Apter Power

PHONE +86 180 3023 5313
EMAIL sales13@apterpower.com
WEBSITE www.apterpower.com

Share the exact MU-TAMT02 51401491-100 nameplate, application and required quantity for a model-specific quotation.