FIELD WORKFLOW

Honeywell 10018/2/U

Safety Manager Module

Honeywell 10018/2/U is identified in the Honeywell coax-platform phase-out table as an FSC node Safety Manager module with the description FSC-SMM CC.

Release-gate sequence

1. IDENTIFY
2. ISOLATE
3. INSTALL
4. STATIC CHECK
5. FUNCTION TEST
6. ACCEPT

Before work starts

- Confirm the complete 10018/2/U code on the installed module.
- Record the FSC-SMM CC designation and FSC node position.
- Capture the current safety configuration and diagnostic state.
- Identify the site-approved safety-system maintenance procedure.
- Plan spare or repair work around the Phased Out lifecycle status.
- Record adjacent labels and cable identifiers before isolation.

Field record essentials

MODEL ID

Record 10018/2/U exactly.

SYSTEM

Legacy Honeywell FSC Safety Manager node

SETTINGS

Preserve the verified installed configuration.

TEST BASIS

Define static and functional acceptance evidence.

Pre-installation verification

CHECK 01

Confirm the complete 10018/2/U code on the installed module.

CHECK 02

Record the FSC-SMM CC designation and FSC node position.

CHECK 03

Capture the current safety configuration and diagnostic state.

CHECK 04

Identify the site-approved safety-system maintenance procedure.

CHECK 05

Plan spare or repair work around the Phased Out lifecycle status.

CHECK 06

Record adjacent labels and cable identifiers before isolation.

Interface inventory

- System context: Legacy Honeywell coax control platform
- Node association: FSC node
- Documented identity: 10018/2/U with FSC-SMM CC description
- Lifecycle path: Phased-out support with modernization assistance available

Hold point

Do not continue if the complete model, field-circuit identity, stored settings, protective functions or safe isolation state cannot be verified. Preserve existing wiring records and escalate the exact unresolved item.

Installation sequence

1. Photograph the exact module label and its cabinet location.
2. Back up site-controlled safety configuration records.
3. Place the affected safety functions in the approved maintenance state.
4. Isolate the node only under the facility's authorized procedure.
5. Preserve slot, connector and cable identity during removal.
6. Inspect mating connections without assuming another FSC module's interfaces.
7. Return the module and connections to the documented positions.
8. Restore the node in the approved controlled sequence.

Commissioning and acceptance

GATE 1

Confirm the restored node recognizes the expected module position.

GATE 2

Compare the as-left configuration with the captured baseline.

GATE 3

Review FSC node diagnostics before functional testing.

GATE 4

Execute the site's required safety-function acceptance procedure.

GATE 5

Verify alarms, permissives and interlocks affected by the maintenance scope.

GATE 6

Resolve any code, slot or configuration mismatch before release.

GATE 7

Document support risks associated with the Phased Out platform.

GATE 8

Archive the final diagnostic state and maintenance handover record.

Fault-response checks

- Module not recognized: compare the installed code and slot with the baseline record.
- Configuration mismatch: stop release and reconcile the controlled safety configuration.
- Persistent node fault: inspect the preserved connector and cable identities.
- Unexpected interlock state: follow the approved safety-function test procedure.
- Spare unavailable: use the documented lifecycle-support route or modernization planning.
- Uncertain module identity: rely on the complete 10018/2/U and FSC-SMM CC markings.

Acceptance boundary

Release only after the normal state, commanded state, principal fault state and recovery behavior have all been observed at the field device, module and control-system indication.

Reference and handover

SOURCE 1 Honeywell December 2025 System HINTS, pages 19-20

Related products

Verified related products on ApterPower

Honeywell FS-TSFIRE-1624
Safety Manager fire I/O module
View Honeywell FS-TSFIRE-1624

Honeywell TA3840C
Industrial control-system component
View Honeywell TA3840C

Honeywell CC-PAIX01 51405038-275
Series C analog-input module
View Honeywell CC-PAIX01 51405038-275

CONFIGURATION
Final settings and mappings archived

WIRING
Terminal and conductor labels reconciled

TEST RECORD
Measured results and fault tests retained

OPERATIONS
Normal indication and response briefed

Contact Apter Power

PHONE +86 180 3023 5313
EMAIL sales13@apterpower.com
WEBSITE www.apterpower.com

Share the exact 10018/2/U nameplate, application and required quantity for a model-specific quotation.