Bently Nevada 84147-01

Installation & Commissioning Guide

Bently Nevada 84147-01 is a hermetically sealed relay module for a compatible 3300/50 Tachometer configuration. It provides the relay hardware used by the selected tachometer alarm arrangement.

PRODUCT ROLE AND VERIFIED FEATURES

Feature 1

Uses hermetically sealed relay construction.

Feature 2

Serves a compatible 3300/50 Tachometer spare configuration.

Feature 3

Interfaces with the monitor's configured alarm logic.

Feature 4

Requires the exact relay option and connector arrangement used by the installed monitor.

VERIFIED DATA SNAPSHOT

Monitor family	3300/50 Tachometer
Component role	Relay module
Relay construction	Hermetically sealed
Control relationship	Operates from configured tachometer alarm logic

SYSTEM RELATIONSHIP

Input condition → **Module logic** → **Relay contact** → **Field circuit**

APTERPOWER SALES TEAM
WhatsApp / Phone: +86 180 3023 5313
Email: sales13@apterpower.com
Scan the approved WhatsApp code for model-specific support.

Pre-installation readiness

READINESS GATE

Identity

Compare the complete marking with the approved work order and installed record.

System match

Confirm the receiving channel, mating components and controlled configuration.

Physical condition

Inspect mounting surfaces, connectors, terminals, cable and support hardware.

Work controls

Apply authorized isolation, bypass, access and restoration procedures.

TECHNICAL PROFILE FOR THE WORK

Monitor family

3300/50 Tachometer

Component role

Relay module

Relay construction

Hermetically sealed

Control relationship

Operates from configured tachometer alarm logic

Replacement rule

Match the installed relay option and monitor execution

Acceptance

Verify contact state and configured alarm response

IMPORTANT NOTICE

Resolve every unmatched interface, configuration or receiving-system condition before removal or installation.

SOURCE AND WORK CONTROLS

Manufacturer source	3300/50 Tachometer Computer/Communications Interface Manual 83871-01
Evidence boundary	Technical statements are limited to the identified product or applicable manufacturer family.
Selection control	Use the complete ordering string and verify the installed system before purchase or installation.


Installation sequence

CONTROLLED WORK STEPS

01	Confirm 84147-01 and the compatible 3300/50 execution before removal.
02	Record each relay contact and external wire before disconnection.
03	De-energize both monitor and external contact circuits.
04	Match the installed relay option and connector orientation.
05	Do not change alarm logic while replacing the relay hardware.
06	Verify insulation, continuity and terminal tightness before energizing.
07	Test normal, alarm and reset contact states.
08	Confirm the receiving shutdown or annunciation circuit before release.

CONNECTION RECORD

As found	Photograph and label every connection and installed orientation before removal.
Mechanical	Record mounting position, support, clearance and connector engagement.
Electrical	Record polarity, common, shield, channel assignment and cable route.
Configuration	Preserve approved settings, scaling, alarm logic and acceptance limits.
As left	Record the final physical condition and any controlled deviation.



WORK HOLD POINTS

Before removal	Identity, position, wiring, orientation and controlled settings recorded.
Before connection	Mating interfaces, condition and routing reviewed.
Before power-up	Mechanical work, wiring, shielding and configuration independently checked.
Before release	Static value, dynamic response and protection behavior accepted.

Commissioning and functional proof

COMMISSIONING SEQUENCE

Initial state

Observe status at power-up and check for unexpected fault or alarm indication.

Static value

Verify the expected bias, gap, loop, contact or channel value for the application.

Dynamic response

Apply the approved machine or test stimulus and confirm response and scaling.

Protection path

Verify the configured alarm, relay, data or receiving-system behavior.

APPLICATION-SPECIFIC EVIDENCE

Alarm relay output

Provide isolated relay contacts for a configured speed alarm.

Tachometer maintenance

Replace the relay module in the matching 3300/50 execution.

Shutdown interface

Transfer an approved alarm state to external logic.

Annunciation

Drive the receiving alarm circuit from the configured monitor event.

ACCEPTANCE RECORD

Identity	Complete marking and final installed position recorded.
Physical inspection	Mounting, connectors, terminals and routing checked.
Channel status	Expected status and configured measurement confirmed.
Functional test	Required output or protection response demonstrated.
Restoration	Bypasses removed and operating state approved.

COMMISSIONING QUESTIONS

What type of component is Bently Nevada 84147-01?	It is a hermetically sealed relay module for a compatible 3300/50 Tachometer configuration.
Which monitor family uses Bently Nevada 84147-01?	It is associated with the 3300/50 Tachometer family.

Release record and technical references

CLOSEOUT QUESTIONS

What construction is used by the relays on Bently Nevada 84147-01?	The relay contacts are hermetically sealed.
What must match before installing Bently Nevada 84147-01?	Match the installed monitor execution, relay option and connector arrangement.
Should alarm settings change when replacing Bently Nevada 84147-01?	No. Preserve the controlled alarm logic unless a separate approved change is issued.
Which circuits require isolation before handling Bently Nevada 84147-01?	Isolate the monitor and every external circuit connected to the relay contacts.
How should Bently Nevada 84147-01 be tested?	Check continuity and verify normal, alarm and reset contact states.
What completes commissioning of Bently Nevada 84147-01?	Confirm the monitor event and the response of the connected shutdown or annunciation circuit.

RELATED MODELS FOR INSTALLATION PLANNING

Bently Nevada 330104-01-08-50-01-cn	Installation-planning reference. Review the complete ordering string before selection.
Bently Nevada 330104-02-10-10-02-00	Installation-planning reference. Compare the required interface and system position.
Bently Nevada 330104-02-12-50-02-00	Installation-planning reference. Confirm the execution independently for the intended task.

MANUFACTURER SOURCE AND FINAL CONTROL

Manufacturer source	3300/50 Tachometer Computer/Communications Interface Manual 83871-01
Evidence boundary	Technical statements are limited to the identified product or applicable manufacturer family.
Selection control	Use the complete ordering string and verify the installed system before purchase or installation.

IMPORTANT NOTICE	Release the equipment only after the responsible site authority accepts the recorded result.

APTERPOWER SALES TEAM
WhatsApp / Phone: +86 180 3023 5313
Email: sales13@apterpower.com
Scan the approved WhatsApp code for model-specific support.