4200N

Primary Extender Module

PUBLISHED IDENTITY

TRICONEX 4200N is the nuclear-qualified Primary Remote Extender Module mapped to the standard fiber-optic 4200 platform. It is installed in the RXM chassis located near the main chassis.

Technical snapshot

Product role	Primary fiber-optic Remote Extender Module
Qualified designation	4200N
Standard-model mapping	4200
Set designation	4200-3 primary RXM set
Installed location	RXM chassis near the Main Chassis
Supported remote locations	Up to three RXM or expansion chassis per primary set
Remote medium	Point-to-point fiber-optic cabling
Maximum published distance	7.5 miles (12 km)

Verified related ApterPower product pages

TRICONEX 3502E

TRICONEX 3503E

Engineering data

Official evidence organized for exact-model review

Product role	Primary fiber-optic Remote Extender Module
Qualified designation	4200N
Standard-model mapping	4200
Set designation	4200-3 primary RXM set
Installed location	RXM chassis near the Main Chassis
Supported remote locations	Up to three RXM or expansion chassis per primary set

Remote medium	Point-to-point fiber-optic cabling
Maximum published distance	7.5 miles (12 km)
RXM power modules	Two per RXM chassis
RXM I/O capacity	Six I/O module slot sets
Qualification class	Tricon v10 nuclear 1E equipment table
Connector control	ST connectors fully seated and locked

EVIDENCE BOUNDARY

Confirm the complete 4200N identity, installed system record and approved companion hardware before replacement or commissioning.

Applications and system role

Four distinct documented operating contexts

INSTALLED TRICON SYSTEMS

Controlled service where the approved system records explicitly identify 4200N.

PLANNED MAINTENANCE

Like-for-like inspection or replacement work that preserves the documented primary extender module arrangement.

LIFECYCLE-MANAGED SPARES

Exact-identity spare control for operating installations that retain the TRICONEX 4200N designation.

COMMISSIONING VERIFICATION

Functional checks that confirm the recorded interface, configuration and diagnostics after 4200N is installed.

Integration control

Manufacturer installation instructions place the primary 4200 set in the RXM chassis near the Main Chassis and use fiber-optic links to remote RXM locations. A primary set can support up to three remote or expansion chassis, while each RXM chassis includes two Power Modules and up to six I/O slot sets. Fiber channels and ST connector engagement must be preserved exactly.

Verified related ApterPower product pages

TRICONEX 3504E

TRICONEX 3511

Technical questions

Complete model-specific answers from the approved evidence set

What function does TRICONEX 4200N perform?

TRICONEX 4200N performs the documented role of a primary extender module within the applicable installed-system architecture.

Which qualified designation is specified for 4200N?

The manufacturer specifies the qualified designation for 4200N as 4200N.

How does the manufacturer define the standard-model mapping of 4200N?

The manufacturer specifies the standard-model mapping for 4200N as 4200.

What set designation applies to the TRICONEX 4200N?

The manufacturer specifies the set designation for 4200N as 4200-3 primary RXM set.

Where does 4200N fit with respect to installed location?

The manufacturer specifies the installed location for 4200N as RXM chassis near the Main Chassis.

Why must the supported remote locations be checked on 4200N?

The manufacturer specifies the supported remote locations for 4200N as Up to three RXM or expansion chassis per primary set.

When replacing 4200N, which remote medium must match the record?

The manufacturer specifies the remote medium for 4200N as Point-to-point fiber-optic cabling.

What does the manual state about the maximum published distance for 4200N?

The manufacturer specifies the maximum published distance for 4200N as 7.5 miles (12 km).

Product precautions

Eight aligned controls before return to service

1. Record the complete TRICONEX 4200N marking and installed position before work.
2. Place the controller and affected process function in the approved safe maintenance state.
3. Verify the documented system version, companion hardware and interface assigned to 4200N.
4. Isolate the applicable controller and field energy in accordance with the approved procedure.
5. Inspect connectors, keys, cable assemblies and mechanical retention before installation.
6. Install 4200N only in the recorded location without changing the approved architecture.
7. Restore power under control and confirm the specified indicators, communications and diagnostics.
8. Document the final identity, configuration and functional acceptance results before release.

Verified related ApterPower product pages

- TRICONEX 3624
- TRICONEX 3664
- TRICONEX 3703E
- TRICONEX 3704E

Evidence and support

Manufacturer references, related products and direct contact

Manufacturer evidence used

- TRICONEX Planning and Installation Guide for Tricon v9-v11 Systems, document 9720100-012.
- TRICONEX Technical Product Guide, document 9791007-013.
- TRICONEX Field Terminations Guide for Tricon v9-v10 Systems, document 9700052-018.

Verified related ApterPower product pages

TRICONEX 4210

TRICONEX 4329

TRICONEX 4119A

TRICONEX 8312

Talk to Apter Power

WHATSAPP / PHONE +86 180 3023 5313

EMAIL sales13@apterpower.com

WEBSITE www.apterpower.com