4000098-510

Exact-identity installation and commissioning guide

PRODUCT SCOPE

TRICONEX 4000098-510 is an exact cable assembly listed for manufacturer termination products associated with Tricon analog-output field connections. The installed termination-panel identity must be verified before the cable is selected.

Verified installation basis

Product role	Termination interface cable assembly
Exact cable number	4000098-510
Published bend radius	6.25 in (15.875 cm)
ETP mapping	9853-610
ETA mapping	3000400-530
Additional assembly mapping	1600049-100
Application class	Analog-output termination

Verified related ApterPower product pages

TRICONEX 3502E

TRICONEX 3503E

Pre-work control

Record the installed system before any disconnection

Required checks

- Record the complete TRICONEX 4000098-510 marking and installed position before work.
- Place the controller and affected process function in the approved safe maintenance state.
- Verify the documented system version, companion hardware and interface assigned to 4000098-510.
- Isolate the applicable controller and field energy in accordance with the approved procedure.
- Inspect connectors, keys, cable assemblies and mechanical retention before installation.
- Install 4000098-510 only in the recorded location without changing the approved architecture.

HOLD POINT

Confirm the complete 4000098-510 identity, installed system record and approved companion hardware before replacement or commissioning.

Evidence to retain

- Complete product and installed-unit marking.
- Approved project, wiring and cabinet records.
- As-found connector, cable, address and diagnostic state.
- Acceptance plan and final results.

Verified related ApterPower product pages

TRICONEX 3504E

TRICONEX 3511

TRICONEX 3624

TRICONEX 3664

TRICONEX 3703E

TRICONEX 3704E

Installation sequence

Use the approved manufacturer procedure and site work controls

1 IDENTIFY

Record the complete TRICONEX 4000098-510 marking and installed position before work.

2 ISOLATE

Place the controller and affected process function in the approved safe maintenance state.

3 RECORD

Verify the documented system version, companion hardware and interface assigned to 4000098-510.

4 VERIFY

Isolate the applicable controller and field energy in accordance with the approved procedure.

5 INSTALL

Inspect connectors, keys, cable assemblies and mechanical retention before installation.

6 RESTORE

Install 4000098-510 only in the recorded location without changing the approved architecture.

CONFIGURATION CONTROL

The field-termination cross-reference assigns this cable to the 9853-610 assembly and also lists it with interface assembly 1600049-100. The cable should not be treated as a universal analog-output lead because the panel, ETA and module architecture remain part of the approved circuit. Routing must preserve the published bend-radius limit and connector engagement.

Verified related ApterPower product pages

TRICONEX 4210

TRICONEX 4329

Commissioning and acceptance

Return each affected function to its approved state

Identity	Record the complete TRICONEX 4000098-510 marking and installed position before work.
Configuration	Install 4000098-510 only in the recorded location without changing the approved architecture.
Physical installation	Restore power under control and confirm the specified indicators, communications and diagnostics.
Functional acceptance	Document the final identity, configuration and functional acceptance results before release.
Diagnostics	Confirm that no unexplained product, communication or system diagnostic remains.
Release record	Document the final configuration, observed states, test results and responsible technician.

Verified related ApterPower product pages

- TRICONEX 4119A
- TRICONEX 8312
- TRICONEX 4000188-320
- TRICONEX 4000188-310

Handover record

Traceable evidence for the installed product

Final acceptance

- Inspect connectors, keys, cable assemblies and mechanical retention before installation.
- Install 4000098-510 only in the recorded location without changing the approved architecture.
- Restore power under control and confirm the specified indicators, communications and diagnostics.
- Document the final identity, configuration and functional acceptance results before release.

Manufacturer evidence used

- TRICONEX Planning and Installation Guide for Tricon v9-v11 Systems, document 9720100-012.
- TRICONEX Technical Product Guide, document 9791007-013.
- TRICONEX Field Terminations Guide for Tricon v9-v10 Systems, document 9700052-018.

Verified related ApterPower product pages

TRICONEX 8311

TRICONEX 4329G

Talk to Apter Power

WHATSAPP / PHONE +86 180 3023 5313

EMAIL sales13@apterpower.com

WEBSITE www.apterpower.com