HCU3700/3703E

Exact-identity installation and commissioning guide

PRODUCT SCOPE

MTL HCU3700/3703E is a HART connection and maintenance unit identified by the manufacturer for Triconex 3700 and 3703E analog-input applications. It provides the documented maintenance interface used to access HART-capable field-device information without treating the unit as a Triconex I/O module.

Verified installation basis

Product role	HART connection and maintenance unit
Exact model	HCU3700/3703E
Manufacturer	MTL
Supported host family	Triconex
Associated host modules	3700 or 3703E analog input
Product family	MTL HART connection system
System purpose	HART field-device configuration, diagnostics and status access

Verified related ApterPower product pages

TRICONEX 3502E

TRICONEX 3503E

Pre-work control

Record the installed system before any disconnection

Required checks

- Record the complete MTL HCU3700/3703E marking and installed position before work.
- Place the controller and affected process function in the approved safe maintenance state.
- Verify the documented system version, companion hardware and interface assigned to HCU3700/3703E.
- Isolate the applicable controller and field energy in accordance with the approved procedure.
- Inspect connectors, keys, cable assemblies and mechanical retention before installation.
- Install HCU3700/3703E only in the recorded location without changing the approved architecture.

HOLD POINT

Confirm the complete HCU3700/3703E identity, installed system record and approved companion hardware before replacement or commissioning.

Evidence to retain

- Complete product and installed-unit marking.
- Approved project, wiring and cabinet records.
- As-found connector, cable, address and diagnostic state.
- Acceptance plan and final results.

Verified related ApterPower product pages

TRICONEX 3504E

TRICONEX 3511

TRICONEX 3624

TRICONEX 3664

TRICONEX 3703E

TRICONEX 3704E

Installation sequence

Use the approved manufacturer procedure and site work controls

1 IDENTIFY

Record the complete MTL HCU3700/3703E marking and installed position before work.

2 ISOLATE

Place the controller and affected process function in the approved safe maintenance state.

3 RECORD

Verify the documented system version, companion hardware and interface assigned to HCU3700/3703E.

4 VERIFY

Isolate the applicable controller and field energy in accordance with the approved procedure.

5 INSTALL

Inspect connectors, keys, cable assemblies and mechanical retention before installation.

6 RESTORE

Install HCU3700/3703E only in the recorded location without changing the approved architecture.

CONFIGURATION CONTROL

The official MTL instruction manual lists the exact HCU3700/3703E designation in its host-system product table, and the manufacturer declaration includes the unit in the MTL HART connection-system product family. The complete unit identity, installed host module, cabinet cabling and HART maintenance arrangement must be reconciled before replacement. System-level cabling guidance may be used only when it matches the installed MTL hardware record.

Verified related ApterPower product pages

TRICONEX 4210

TRICONEX 4329

Commissioning and acceptance

Return each affected function to its approved state

Identity	Record the complete MTL HCU3700/3703E marking and installed position before work.
Configuration	Install HCU3700/3703E only in the recorded location without changing the approved architecture.
Physical installation	Restore power under control and confirm the specified indicators, communications and diagnostics.
Functional acceptance	Document the final identity, configuration and functional acceptance results before release.
Diagnostics	Confirm that no unexplained product, communication or system diagnostic remains.
Release record	Document the final configuration, observed states, test results and responsible technician.

Verified related ApterPower product pages

- TRICONEX 4119A
- TRICONEX 8312
- TRICONEX 4000188-320
- TRICONEX 4000188-310

Handover record

Traceable evidence for the installed product

Final acceptance

- Inspect connectors, keys, cable assemblies and mechanical retention before installation.
- Install HCU3700/3703E only in the recorded location without changing the approved architecture.
- Restore power under control and confirm the specified indicators, communications and diagnostics.
- Document the final identity, configuration and functional acceptance results before release.

Manufacturer evidence used

- MTL4840 HART Connection System Instruction Manual, INM4840-5.
- MTL EU Declaration of Conformity for BPHM/HCU products, MTL17DOCBPHCU.

Verified related ApterPower product pages

TRICONEX 8311

TRICONEX 4329G

Talk to Apter Power

WHATSAPP / PHONE +86 180 3023 5313

EMAIL sales13@apterpower.com

WEBSITE www.apterpower.com