GE DS200LDCCH1ALA DS200LDCCH1

Installation & Commissioning Guide

GE DS200LDCCH1ALA DS200LDCCH1 is a drive control and communications board identified for service in a matched legacy GE control assembly; the complete suffix must be retained during replacement.

PRODUCT ROLE AND TECHNICAL FEATURES

Feature 1

Uses the DS200 board-family identification.

Feature 2

Provides drive control and communications functions in the installed control assembly.

Feature 3

Retains the complete suffix as part of the replacement identity.

Feature 4

Requires the original connector, slot and wiring relationship to be preserved.

TECHNICAL DATA SNAPSHOT

Product form	Printed circuit board assembly
Platform family	DS200
Functional area	Drive control and communications functions
Installation position	Matched existing board position

SYSTEM RELATIONSHIP

Field device → **Product interface** → **System channel** → **Verified response**

APTERPOWER SALES TEAM
WhatsApp / Phone: +86 180 3023 5313
Email: sales13@apterpower.com
Scan the approved WhatsApp code for model-specific support.

Pre-installation readiness

READINESS GATE

Identity

Compare the complete marking with the approved work order and installed record.

System match

Confirm the receiving channel, mating components and controlled configuration.

Physical condition

Inspect mounting surfaces, connectors, terminals, cable and support hardware.

Work controls

Apply authorized isolation, bypass, access and restoration procedures.

TECHNICAL PROFILE FOR THE WORK

Product form Printed circuit board assembly	**Platform family** DS200
Functional area Drive control and communications functions	**Installation position** Matched existing board position
Connection basis Existing harnesses, connectors and backplane interfaces	**Identity control** Complete catalog number and suffix required
Replacement method Like-for-like controlled substitution	**Commissioning basis** System diagnostics and affected-circuit functional checks

IMPORTANT NOTICE Resolve every unmatched interface, configuration or receiving-system condition before removal or installation.

DOCUMENT AND WORK CONTROLS

Manufacturer document	Exact product marking and verified GE board-family/document references available for this legacy assembly.
Application scope	The values below apply to the identified product and its documented system relationship.
Selection rule	Use the complete ordering string and confirm the installed interfaces before selection.

APTERPOWER SALES TEAM
WhatsApp / Phone: +86 180 3023 5313
Email: sales13@apterpower.com
Scan the approved WhatsApp code for model-specific support.

Installation sequence

CONTROLLED WORK STEPS

01	Confirm the complete DS200LDCCH1ALA DS200LDCCH1 marking before removing the installed board.
02	De-energize the equipment and follow the approved stored-energy procedure.
03	Photograph and label every connector, jumper and cable before disconnection.
04	Use ESD controls when handling the printed circuit board assembly.
05	Inspect connector keys, edge contacts and card guides before insertion.
06	Do not transfer jumpers or configurable devices until their original positions are recorded.
07	Restore every harness and shield to the documented termination point.
08	Run the affected system diagnostics and functional checks before release.

CONNECTION RECORD

As found	Photograph and label every connection and installed orientation before removal.
Mechanical	Record mounting position, support, clearance and connector engagement.
Electrical	Record polarity, common, shield, channel assignment and cable route.
Configuration	Preserve approved settings, scaling, alarm logic and acceptance limits.
As left	Record the final physical condition and any controlled deviation.

Field device → **Product interface** → **System channel** → **Verified response**

WORK HOLD POINTS

Before removal	Identity, position, wiring, orientation and controlled settings recorded.
Before connection	Mating interfaces, condition and routing reviewed.
Before power-up	Mechanical work, wiring, shielding and configuration independently checked.
Before release	Static value, dynamic response and protection behavior accepted.

Commissioning and functional proof

COMMISSIONING SEQUENCE

Initial state

Observe status at power-up and check for unexpected fault or alarm indication.

Static value

Verify the expected bias, gap, loop, contact or channel value for the application.

Dynamic response

Apply the approved machine or test stimulus and confirm response and scaling.

Protection path

Verify the configured alarm, relay, data or receiving-system behavior.

APPLICATION-SPECIFIC CHECKS

Controlled board replacement

Restores the documented board position after the installed identity and interfaces are matched.

Legacy control maintenance

Supports service work on equipment using the DS200 board family.

Interface-path recovery

Returns the affected drive control and communications functions after connector and wiring checks.

Diagnostic troubleshooting

Provides a defined replacement point when system tests isolate the fault to this board assembly.

ACCEPTANCE RECORD

Identity	Complete marking and final installed position recorded.
Physical inspection	Mounting, connectors, terminals and routing checked.
Channel status	Expected status and configured measurement confirmed.
Functional test	Required output or protection response demonstrated.
Restoration	Bypasses removed and operating state approved.

COMMISSIONING QUESTIONS

What equipment identity must be matched before installing GE DS200LDCCH1ALA DS200LDCCH1?	Match the complete DS200LDCCH1ALA DS200LDCCH1 marking, board position, connector pattern and installed-system documentation.
Why is the suffix important on GE DS200LDCCH1ALA DS200LDCCH1?	The suffix is part of the complete board identity and should be preserved during like-for-like replacement.

Release record and technical references

CLOSEOUT QUESTIONS

Which connections should be recorded before GE DS200LDCCH1ALA DS200LDCCH1 is removed?	Record every plug, keyed connector, jumper, cable label, shield and terminal relationship associated with the installed board.
How should GE DS200LDCCH1ALA DS200LDCCH1 be handled during service?	Use approved ESD handling and support the board by its edges without loading components or connector pins.
What should be inspected before seating GE DS200LDCCH1ALA DS200LDCCH1?	Inspect card guides, connector keys, mating contacts, harness condition and the intended board position.
Can GE DS200LDCCH1ALA DS200LDCCH1 be substituted using only a shortened base number?	No. Use the complete catalog string and confirm the installed interfaces before substitution.
Which checks should follow installation of GE DS200LDCCH1ALA DS200LDCCH1?	Run the affected controller or drive diagnostics, verify connected circuits and confirm the expected system response.
When should GE DS200LDCCH1ALA DS200LDCCH1 be returned to service?	Release the equipment only after connector security, configuration records and all affected functional checks are complete.

RELATED MODELS FOR INSTALLATION PLANNING

GE 531X304IBDANG1 F31X304IBDAMG1	Installation-planning reference. Review the complete ordering string before selection.
GE DS200ADPBG1ABB	Installation-planning reference. Compare the required interface and system position.
GE IC697ALG440	Installation-planning reference. Confirm the execution independently for the intended task.

MANUFACTURER DOCUMENT AND FINAL CONTROL

Manufacturer document	Exact product marking and verified GE board-family/document references available for this legacy assembly.
Application scope	The values below apply to the identified product and its documented system relationship.
Selection rule	Use the complete ordering string and confirm the installed interfaces before selection.

IMPORTANT NOTICE	Release the equipment only after the responsible site authority accepts the recorded result.

APTERPOWER SALES TEAM
WhatsApp / Phone: +86 180 3023 5313
Email: sales13@apterpower.com
Scan the approved WhatsApp code for model-specific support.