Bently Nevada 3701/60A

Installation & Commissioning Guide

Bently Nevada 3701/60A is a wind-turbine condition-monitoring platform for collecting machinery vibration and operating-condition data.

PRODUCT ROLE AND TECHNICAL FEATURES

Feature 1

Collects turbine drivetrain condition signals.

Feature 2

Supports vibration trending across critical rotating components.

Feature 3

Provides a dedicated platform for wind-turbine monitoring.

Feature 4

Integrates measured data with diagnostic and maintenance workflows.

TECHNICAL DATA SNAPSHOT

System family	3701 wind monitoring
Primary asset	Wind turbine drivetrain
Monitoring role	Condition and vibration monitoring
Typical measurement points	Bearings, gearbox, generator and rotor train

SYSTEM RELATIONSHIP

Field device → **Product interface** → **System channel** → **Verified response**

APTERPOWER SALES TEAM
WhatsApp / Phone: +86 180 3023 5313
Email: sales13@apterpower.com
Scan the approved WhatsApp code for model-specific support.

Pre-installation readiness

READINESS GATE

Identity

Compare the complete marking with the approved work order and installed record.

System match

Confirm the receiving channel, mating components and controlled configuration.

Physical condition

Inspect mounting surfaces, connectors, terminals, cable and support hardware.

Work controls

Apply authorized isolation, bypass, access and restoration procedures.

TECHNICAL PROFILE FOR THE WORK

System family 3701 wind monitoring	**Primary asset** Wind turbine drivetrain
Monitoring role Condition and vibration monitoring	**Typical measurement points** Bearings, gearbox, generator and rotor train
Data use Trending, diagnostics and maintenance planning	**Signal sources** Installed vibration and condition sensors
Retrofit relationship Supported by documented 3701/60A retrofit hardware	**Acceptance method** Verify channel mapping, signal quality and communications

IMPORTANT NOTICE	Resolve every unmatched interface, configuration or receiving-system condition before removal or installation.

DOCUMENT AND WORK CONTROLS

Manufacturer document	ApterPower product-specific technical reference
Application scope	The values below apply to the identified product and its documented system relationship.
Selection rule	Use the complete ordering string and confirm the installed interfaces before selection.

APTERPOWER SALES TEAM
WhatsApp / Phone: +86 180 3023 5313
Email: sales13@apterpower.com
Scan the approved WhatsApp code for model-specific support.

Installation sequence

CONTROLLED WORK STEPS

01	Confirm the complete 3701/60A marking and the documented wind turbine condition monitor position.
02	Place the affected machine protection channel in the approved maintenance state.
03	Record the installed system family, primary asset and monitoring role before removal.
04	De-energize the associated monitor, sensor supply or field circuit as the procedure requires.
05	Label every connector, conductor and shield before separation.
06	Inspect mating contacts, mounting hardware and cable condition before installation.
07	Restore the retained configuration and verify signal polarity and proportional response.
08	Function-test the complete alarm, indication and shutdown path before returning the machine to service.

CONNECTION RECORD

As found	Photograph and label every connection and installed orientation before removal.
Mechanical	Record mounting position, support, clearance and connector engagement.
Electrical	Record polarity, common, shield, channel assignment and cable route.
Configuration	Preserve approved settings, scaling, alarm logic and acceptance limits.
As left	Record the final physical condition and any controlled deviation.

Field device → **Product interface** → **System channel** → **Verified response**

WORK HOLD POINTS

Before removal	Identity, position, wiring, orientation and controlled settings recorded.
Before connection	Mating interfaces, condition and routing reviewed.
Before power-up	Mechanical work, wiring, shielding and configuration independently checked.
Before release	Static value, dynamic response and protection behavior accepted.

Commissioning and functional proof

COMMISSIONING SEQUENCE

Initial state

Observe status at power-up and check for unexpected fault or alarm indication.

Static value

Verify the expected bias, gap, loop, contact or channel value for the application.

Dynamic response

Apply the approved machine or test stimulus and confirm response and scaling.

Protection path

Verify the configured alarm, relay, data or receiving-system behavior.

APPLICATION-SPECIFIC CHECKS

Gearbox condition monitoring

Tracks bearing and gear vibration patterns.

Generator monitoring

Supervises generator-bearing condition.

Main-bearing trending

Records long-term vibration changes.

Wind-farm maintenance

Supports condition-based maintenance decisions.

ACCEPTANCE RECORD

Identity	Complete marking and final installed position recorded.
Physical inspection	Mounting, connectors, terminals and routing checked.
Channel status	Expected status and configured measurement confirmed.
Functional test	Required output or protection response demonstrated.
Restoration	Bypasses removed and operating state approved.

COMMISSIONING QUESTIONS

How is system family tested on Bently Nevada 3701/60A?	The documented system family is 3701 wind monitoring; confirm it against the installed record.
Which record preserves primary asset for Bently Nevada 3701/60A?	The documented primary asset is Wind turbine drivetrain; confirm it against the installed record.

Release record and technical references

CLOSEOUT QUESTIONS

Which monitoring role applies to Bently Nevada 3701/60A?	The documented monitoring role is Condition and vibration monitoring; confirm it against the installed record.
How is typical measurement points set on Bently Nevada 3701/60A?	The documented typical measurement points is Bearings, gearbox, generator and rotor train; confirm it against the installed record.
What data use belongs to Bently Nevada 3701/60A?	The documented data use is Trending, diagnostics and maintenance planning; confirm it against the installed record.
Why verify signal sources for Bently Nevada 3701/60A?	The documented signal sources is Installed vibration and condition sensors; confirm it against the installed record.
Where is retrofit relationship used by Bently Nevada 3701/60A?	The documented retrofit relationship is Supported by documented 3701/60A retrofit hardware; confirm it against the installed record.
What controls acceptance method on Bently Nevada 3701/60A?	The documented acceptance method is Verify channel mapping, signal quality and communications; confirm it against the installed record.

RELATED MODELS FOR INSTALLATION PLANNING

Bently Nevada 330980-51-CN	Installation-planning reference. Review the complete ordering string before selection.
Bently Nevada 330750-40	Installation-planning reference. Compare the required interface and system position.
Bently Nevada 330180-X2-05	Installation-planning reference. Confirm the execution independently for the intended task.

MANUFACTURER DOCUMENT AND FINAL CONTROL

Manufacturer document	ApterPower product-specific technical reference
Application scope	The values below apply to the identified product and its documented system relationship.
Selection rule	Use the complete ordering string and confirm the installed interfaces before selection.

IMPORTANT NOTICE	Release the equipment only after the responsible site authority accepts the recorded result.

APTERPOWER SALES TEAM
WhatsApp / Phone: +86 180 3023 5313
Email: sales13@apterpower.com
Scan the approved WhatsApp code for model-specific support.