Emerson KJ3222X1-BA1 12P2532X122 VE4033S2B1

Installation & Commissioning Guide

Emerson KJ3222X1-BA1 12P2532X122 VE4033S2B1 combines an eight-channel 4-20 mA HART analog-input card with the documented redundant standard i/o termination block execution.

PRODUCT ROLE AND VERIFIED FEATURES

Feature 1

Acquires eight independent 4-20 mA process signals.

Feature 2

Supports HART digital communication on each analog loop.

Feature 3

Provides channel-to-channel and system isolation.

Feature 4

Uses the redundant standard i/o termination block configuration identified by the complete assembly code.

VERIFIED DATA SNAPSHOT

Input channels	8
Input signal	4 to 20 mA with HART
Channel isolation	Each channel optically isolated from the system and other channels
Input range	2 to 22 mA full signal range
Terminal execution	Redundant standard I/O termination block
DeltaV support	Traditional M-series I/O

SYSTEM RELATIONSHIP

Field signal → **Termination** → **Input module** → **Control database**

APTERPOWER SALES TEAM
WhatsApp / Phone: +86 180 3023 5313
Email: sales13@apterpower.com
Scan the approved WhatsApp code for model-specific support.

Pre-installation readiness

READINESS GATE

Identity

Compare the complete marking with the approved work order and installed record.

System match

Confirm the receiving channel, mating components and controlled configuration.

Physical condition

Inspect mounting surfaces, connectors, terminals, cable and support hardware.

Work controls

Apply authorized isolation, bypass, access and restoration procedures.

TECHNICAL PROFILE FOR THE WORK

Input channels

8

Input signal

4 to 20 mA with HART

Channel isolation

Each channel optically isolated from the system and other channels

Input range

2 to 22 mA full signal range

Terminal execution

Redundant standard I/O termination block

DeltaV support

Traditional M-series I/O

IMPORTANT NOTICE

Resolve every unmatched interface, configuration or receiving-system condition before removal or installation.

CONFIGURATION AND WORK CONTROLS

Configuration identity	Emerson KJ3222X1-BA1 12P2532X122 VE4033S2B1
Technical boundary	Apply only the functions and interfaces shown for this product or its identified system family.
Selection control	Match the complete ordering string and installed interfaces before purchase or installation.


Installation sequence

CONTROLLED WORK STEPS

01	Match the complete card, 12P and VE identifiers before work.
02	Record all eight loop assignments and HART device tags.
03	Remove field power before changing terminal-block connections.
04	Preserve polarity, shields and the keyed terminal execution.
05	Inspect the card and termination block for incomplete engagement.
06	Restore configured ranges and damping without copying another channel.
07	Verify analog values and HART device identities after startup.
08	Confirm diagnostics, alarms and controller quality before release.

CONNECTION RECORD

As found	Photograph and label every connection and installed orientation before removal.
Mechanical	Record mounting position, support, clearance and connector engagement.
Electrical	Record polarity, common, shield, channel assignment and cable route.
Configuration	Preserve approved settings, scaling, alarm logic and acceptance limits.
As left	Record the final physical condition and any controlled deviation.



WORK HOLD POINTS

Before removal	Identity, position, wiring, orientation and controlled settings recorded.
Before connection	Mating interfaces, condition and routing reviewed.
Before power-up	Mechanical work, wiring, shielding and configuration independently checked.
Before release	Static value, dynamic response and protection behavior accepted.

Commissioning and functional proof

COMMISSIONING SEQUENCE

Initial state

Observe status at power-up and check for unexpected fault or alarm indication.

Static value

Verify the expected bias, gap, loop, contact or channel value for the application.

Dynamic response

Apply the approved machine or test stimulus and confirm response and scaling.

Protection path

Verify the configured alarm, relay, data or receiving-system behavior.

APPLICATION-SPECIFIC EVIDENCE

Pressure transmitter inputs

Reads 4-20 mA measurement and HART device data.

Flow measurement loops

Connects intelligent flow instruments to DeltaV I/O.

Level and temperature transmitters

Accepts standard two-wire HART transmitter signals.

Redundant process measurement

Supports the documented termination architecture for critical inputs.

ACCEPTANCE RECORD

Identity	Complete marking and final installed position recorded.
Physical inspection	Mounting, connectors, terminals and routing checked.
Channel status	Expected status and configured measurement confirmed.
Functional test	Required output or protection response demonstrated.
Restoration	Bypasses removed and operating state approved.

COMMISSIONING QUESTIONS

Which input channels applies to KJ3222X1-BA1 12P2532X122 VE4033S2B1?	The documented input channels is 8.
How is KJ3222X1-BA1 12P2532X122 VE4033S2B1 specified for input signal?	The documented input signal is 4 to 20 mA with HART.
What channel isolation should be checked on KJ3222X1-BA1 12P2532X122 VE4033S2B1?	The documented channel isolation is Each channel optically isolated from the system and other channels.
Why does input range matter when selecting KJ3222X1-BA1 12P2532X122 VE4033S2B1?	The documented input range is 2 to 22 mA full signal range.

Release record and technical references

CLOSEOUT QUESTIONS

Where does KJ3222X1-BA1 12P2532X122 VE4033S2B1 use its stated terminal execution?	The documented terminal execution is Redundant standard I/O termination block.
What value is documented for the deltav support of KJ3222X1-BA1 12P2532X122 VE4033S2B1?	The documented deltav support is Traditional M-series I/O.
Which records should be retained before removing KJ3222X1-BA1 12P2532X122 VE4033S2B1?	Record the complete marking, installed position, wiring, keying and controlled configuration before removal.
Which acceptance checks should follow installation of KJ3222X1-BA1 12P2532X122 VE4033S2B1?	Verify physical engagement, channel status, diagnostics and the intended signal or communication response before release.

RELATED MODELS FOR INSTALLATION PLANNING

Emerson PR6423/004-111 CON041	Installation-planning reference. Review the complete ordering string before selection.
Emerson PR6423/00R-111 CON041	Installation-planning reference. Compare the required interface and system position.
Emerson PR6423/012-100 CON011	Installation-planning reference. Confirm the execution independently for the intended task.

CONFIGURATION AND FINAL CONTROL

Configuration identity	Emerson KJ3222X1-BA1 12P2532X122 VE4033S2B1
Technical boundary	Apply only the functions and interfaces shown for this product or its identified system family.
Selection control	Match the complete ordering string and installed interfaces before purchase or installation.

IMPORTANT NOTICE	Release the equipment only after the responsible site authority accepts the recorded result.

APTERPOWER SALES TEAM
WhatsApp / Phone: +86 180 3023 5313
Email: sales13@apterpower.com
Scan the approved WhatsApp code for model-specific support.