# HIMA F-BASE RACK 01

H51X Base Rack

**01 / PREPARATION, RESTORATION AND ACCEPTANCE**

Planning aid for HIMA F-BASE RACK 01. Use the applicable equipment instructions and authorized site procedure for physical work and test execution. The checks below apply the documented model distinctions; they do not introduce undocumented device limits.

## Controlled work sequence

### 01 / Confirm H51X and base-rack scope

Match the installed assembly to F-BASE RACK 01 in the equipment list. Distinguish the base position from any extension racks in the cabinet.

### 02 / Capture the complete population map

Record each installed module and its position using the actual cabinet documentation. The short rack listing is not a slot-assignment or backplane pinout drawing.

### 03 / Control any version change

If a replacement proposal adds the R suffix or changes the rack number, treat it as a configuration change requiring the applicable engineering review.

### 04 / Restore and test the assembled system

Use the controlled rack installation procedure, then verify the restored module assignments and required system functions. Acceptance applies to the assembled H51X configuration.

## Model-specific acceptance checks

| Subject | Expected evidence |
| --- | --- |
| **Rack role** | The as-left record identifies the H51X base rack. |
| **Exact variant** | F-BASE RACK 01 is distinguished from 01 R. |
| **Module arrangement** | The restored population map matches the authorized configuration. |

## More Apter Power catalog references

Catalog navigation only; no compatibility or substitution implied.

HIMA F3422 | View product page

HIMA F3423 | View product page

# HIMA F-BASE RACK 01

H51X Base Rack



### The suffix changed in a quotation

Check the actual assembly offered. The portfolio treats the rugged R variant as a separate entry.

### The rack fits but the configuration differs

Physical fit does not prove the approved module arrangement or system behavior. Reconcile the documented population map.

## If a check fails

Rack role: Resolve an extension-rack designation before proceeding.

Exact variant: Obtain approval for a proposed version change.

Module arrangement: Resolve slot or module discrepancies before the system test.

## Technical reference record

Technical overview | Safety platform and products, reviewed 23 October 2026 - HIQuad X section; base-rack and extension-rack rows.

## Related Apter Power catalog references

Catalog navigation only. These entries do not establish compatibility, substitution or approval of a changed installation.

HIMA F3316 | View HIMA F3316 page

HIMA F6221 | View HIMA F6221 page

HIMA F3240 | View HIMA F3240 page

**CONTACT APTER POWER**

WHATSAPP / PHONE +86 180 3023 5313

EMAIL sales13@apterpower.com

WEBSITE www.apterpower.com

Send the exact model, quantity and requested condition for a quotation.

F-BASE RACK 01