Bently Nevada 3300/25-03-06-06-01-00-02-00

01 Exact-model technical scope

Configuration represented by this reference

Bently Nevada 3300/25-03-06-06-01-00-02-00 is a 3300/25 Dual Accelerometer Monitor configured for Channel A 0–2 in/s pk; Channel B 0–2 in/s pk with Dual accelerometer input; two velocity channels; its selected hardware provides Hermetically sealed alarm relays, a standard unbarriered input interface, CSA/NRTL/C approval selection, the base displayed range. This reference treats the complete order code as one configuration; values from another range, input, relay or barrier variant are not transferred into this selection.

Selected technical configuration

Technical item	Selected value
Measurement function	dual-channel casing vibration
Selected channel ranges	Channel A 0–2 in/s pk; Channel B 0–2 in/s pk
Input and processing	Dual accelerometer input; two velocity channels
Channel count	2 measurement channels
Alarm relay option	Hermetically sealed
Safety-barrier option	None
Agency approval option	CSA/NRTL/C
Range multiplier	None

Measurement boundaries

3300/25 Dual Accelerometer Monitor
The monitor family defines the processing architecture.

Range
Channel A 0–2 in/s pk; Channel B 0–2 in/s pk is the selected display and alarm basis.

Input
Dual accelerometer input; two velocity channels is the required source configuration.

Outputs
Hermetically sealed relay selection and the recorder or indication path must be assessed separately.

Use the complete code

A family number identifies the monitor function, but the remaining code groups determine the usable range and interfaces. Match the complete marking before changing a monitor, rear interface or field transducer.

Bently Nevada 3300/25-03-06-06-01-00-02-00

02 Signal path and selected options

Order-code selections

Selection	Configured choice
Measurement range	Channel A 0–2 in/s pk; Channel B 0–2 in/s pk
Input / processing	Dual accelerometer input; two velocity channels
Alarm relay option	Hermetically sealed
Safety-barrier option	None
Approval selection	CSA/NRTL/C
Range multiplier	None

Range and input form one conversion

The selected range is meaningful only when the connected input system and sensitivity agree with the monitor configuration. A stable value is not proof of correct scaling; apply a controlled signal change and compare the expected and displayed response.

Interface review

Relay path
Test contact logic and downstream wiring.

Unbarriered path
Review the full loop before adding a barrier.

Approval marking
CSA/NRTL/C is selected; verify the assembly marking.

Base range
The stated range applies without multiplication.

Check one channel at a time

Identify the source, monitor channel, local indication, recorder destination and alarm path before applying a test. A one-channel-at-a-time sequence exposes crossed wiring without relying on labels alone.

Bently Nevada 3300/25-03-06-06-01-00-02-00

03 Measurement use and application limits

Common applications

Absolute Housing Vibration Monitoring
Apply the selected Channel A 0–2 in/s pk; Channel B 0–2 in/s pk span to the intended machine measurement.

Two-channel condition monitoring
Keep channel identity from the field transducer through indication and alarms.

Controlled maintenance testing
Inject or apply a known change and compare each response stage.

Protection-system integration
Verify the selected relay and barrier interface with the receiving circuit.

Technical evaluation sequence

01	Confirm the exact model and selected range.
02	Trace the intended transducer signal to its monitor input.
03	Apply a known change within the selected measurement span.
04	Compare local indication and the selected output path.
05	Restore the recorded settings and normal machine-protection state.

Acceptance observations

Configured item	Acceptance point
Channel A 0–2 in/s pk; Channel B 0–2 in/s pk	Check the active span and units.
Dual accelerometer input; two velocity channels	Confirm source type, sensitivity and polarity.
Hermetically sealed	Verify relay presence and contact behavior.
None	Confirm the corresponding field interface.
None	Include the multiplier state in setpoint calculations.

Application boundary

The complete channel must preserve the transducer source, displayed range, relay interface and barrier selection together. A monitor from the same family can produce a plausible indication while applying a different scale or output arrangement.

Bently Nevada 3300/25-03-06-06-01-00-02-00

04 Technical questions for this exact model

Questions 1–4

Can 3300/25-03-06-06-01-00-02-00 use setpoints copied from a monitor with a different range?
The selected measurement span is Channel A 0–2 in/s pk; Channel B 0–2 in/s pk. Alarm and recorder scaling must be checked against that span rather than copied from a different range option.

How should the Dual accelerometer input; two velocity channels source be checked before connecting 3300/25-03-06-06-01-00-02-00?
This configuration uses Dual accelerometer input; two velocity channels. Preserve the transducer family, sensitivity and signal polarity as one measurement chain.

How should the hermetically sealed alarm relays in 3300/25-03-06-06-01-00-02-00 be tested?
The selected alarm output uses hermetically sealed relay hardware. Contact logic, energization and downstream wiring still require a functional test.

Can a safety barrier be added to 3300/25-03-06-06-01-00-02-00 without reviewing the signal loop?
No safety-barrier option is selected. Do not move field conductors from a barrier-equipped circuit without an engineering review.

Core configuration values

Item	Value
Measurement range	Channel A 0–2 in/s pk; Channel B 0–2 in/s pk
Input / processing	Dual accelerometer input; two velocity channels
Alarm relay option	Hermetically sealed
Safety-barrier option	None

Interpret answers as a complete path

Each answer applies to this exact order code. Compare the selected transducer, monitor scale and physical machine condition at the same stable test point instead of treating any single reading as sufficient evidence.

Retain channel identity

Record which field source, display, recorder destination and alarm circuit belong together before any conductor is moved.

Bently Nevada 3300/25-03-06-06-01-00-02-00

05 Output, replacement and release questions

Questions 5–8

Does the CSA/NRTL/C option on 3300/25-03-06-06-01-00-02-00 replace installation compliance checks?
The complete order code selects CSA/NRTL/C. Retain the marked assembly and its installation conditions.

Why must multiplier jumpers be checked even though 3300/25-03-06-06-01-00-02-00 selects no multiplication?
No range multiplier is selected, so the stated scale is the active base range. A multiplied setting from another monitor must not be transferred.

Which functional test should precede return of 3300/25-03-06-06-01-00-02-00 to service?
Apply a controlled input change to one identified channel at a time, then compare the local indication, buffered or recorder signal, alarm state and return to normal.

Which technical settings should be recorded after commissioning 3300/25-03-06-06-01-00-02-00?
Record the complete model, Channel A 0–2 in/s pk; Channel B 0–2 in/s pk scale, Dual accelerometer input; two velocity channels input, relay and barrier choices, channel assignments, setpoints, delays and the observed acceptance results.

Related Bently Nevada product references

Bently Nevada 330103-02-04-10-02-CN

Bently Nevada 330103-02-08-10-02-CN

Replacement boundary

Related monitors and transducers may use different ranges, sensitivities, power requirements, barrier arrangements or relay hardware. Review their complete codes independently before using them as replacements.

Final technical record

Use a controlled input condition to verify the Channel A 0–2 in/s pk; Channel B 0–2 in/s pk scale, Dual accelerometer input; two velocity channels conversion, channel identity and selected output behavior. Restore the recorded alarm, delay, reset, multiplier and bypass states only after the complete path responds correctly.