Bently Nevada 3300/35-05-02-01-00-00

01 Product function and configuration

Exact product role

Bently Nevada 3300/35-05-02-01-00-00 applies six independent three-wire RTD temperature inputs to bearing, winding or process temperature monitoring, using the exact 0–1000 °F scale and the selected interface options.

Technical specification summary

Technical item	Specification
Measurement function	six-channel temperature monitoring
Selected temperature range	0–1000 °F
Sensor input	Pt100, α=0.00385, three-wire
Input wiring	Three-wire RTD
Channel count	6 independent temperature channels
Alarm relay option	Epoxy-sealed
Safety-barrier option	None
Agency approval option	None
Sensor check	Lead identity and stable simulated resistance
Acceptance method	Each channel checked across the selected temperature span

Selected characteristics

Uses the selected 0–1000 °F measurement range.
Range and unit selection

Accepts Pt100, α=0.00385, three-wire.
Input compatibility

Uses epoxy-sealed alarm relay hardware.
Output hardware

Uses the base range without a multiplication option.
Interface selection

Configuration notice

Match the complete 3300/35-05-02-01-00-00 order code, input source and rear connection assembly before installation; then verify each channel through a controlled response test.

Bently Nevada 3300/35-05-02-01-00-00

02 Technical selections in context

Configured measurement path

Order-code function	Selected configuration
Measurement range	0–1000 °F
Input / processing	Pt100, α=0.00385, three-wire
Alarm relay option	Epoxy-sealed
Safety-barrier option	None
Approval selection	None
Range multiplier	None

Signal-chain interpretation

The transducer, field wiring, monitor input, selected span and output path form one chain. Confirm them together when diagnosing scale, polarity, alarm or recorder discrepancies.

Technical decisions

Range suitability
Confirm 0–1000 °F covers the intended machine behavior.

Input match
Use Pt100, α=0.00385, three-wire and preserve its sensitivity.

Output match
Apply Epoxy-sealed relay hardware as selected.

Interface match
Apply None barrier arrangement and None multiplication.

Do not infer unspecified data

Only exact-model technical selections are stated. Installation-specific setpoints, channel destinations and machine limits must be taken from the controlled site configuration.

Bently Nevada 3300/35-05-02-01-00-00

03 Applications and commissioning logic

Application areas

Bearing, Winding Or Process Temperature Monitoring
Apply the selected 0–1000 °F span to the intended machine measurement.

Two-channel condition monitoring
Keep channel identity from the field transducer through indication and alarms.

Controlled maintenance testing
Inject or apply a known change and compare each response stage.

Protection-system integration
Verify the selected relay and barrier interface with the receiving circuit.

Commissioning logic

01	Confirm model identity and rear interface.
02	Check input family and selected range.
03	Prove channel assignment with a controlled change.
04	Test indication, recorder output and alarm behavior separately.
05	Restore normal configuration and record the result.

Selected checks

Technical check	Required value
Channel count	6 independent temperature channels
Alarm relay option	Epoxy-sealed
Safety-barrier option	None
Agency approval option	None
Sensor check	Lead identity and stable simulated resistance
Acceptance method	Each channel checked across the selected temperature span

Machine application

3300/35 Six-Channel Temperature Monitor is used for 35-family monitoring functions represented by the selected input and range. Apply site alarm limits only after the complete response is confirmed.

Bently Nevada 3300/35-05-02-01-00-00

04 Model-specific technical questions

Questions 1–4

How should the 0–1000 °F scale be validated on 3300/35-05-02-01-00-00?
The selected measurement span is 0–1000 °F. Alarm and recorder scaling must be checked against that span rather than copied from a different range option.

How does the Pt100, α=0.00385, three-wire selection affect 3300/35-05-02-01-00-00 calibration?
This configuration uses Pt100, α=0.00385, three-wire. Preserve the transducer family, sensitivity and signal polarity as one measurement chain.

Why must 3300/35-05-02-01-00-00 relay contact logic be checked after installation?
The selected alarm output uses epoxy-sealed relay hardware. Contact logic, energization and downstream wiring still require a functional test.

Which interface assumption is unsafe for the unbarriered 3300/35-05-02-01-00-00?
No safety-barrier option is selected. Do not move field conductors from a barrier-equipped circuit without an engineering review.

Selected hardware context

Item	Configuration
Measurement range	0–1000 °F
Input / processing	Pt100, α=0.00385, three-wire
Alarm relay option	Epoxy-sealed
Safety-barrier option	None
Approval selection	None
Range multiplier	None

Question scope

The questions focus on the range, input and interface options in this exact model. They are not generic interchangeability claims for every monitor in the same family.

Bently Nevada 3300/35-05-02-01-00-00

05 Configuration, testing and related products

Questions 5–8

Does the product family name alone establish an approval for 3300/35-05-02-01-00-00?
No agency-approval option is selected in this order code. Do not infer an approval from another unit in the same monitor family.

How is the base range interpreted when 3300/35-05-02-01-00-00 has no multiplier?
No range multiplier is selected, so the stated scale is the active base range. A multiplied setting from another monitor must not be transferred.

How can a transducer fault be separated from a real alarm on 3300/35-05-02-01-00-00?
Apply a controlled input change to one identified channel at a time, then compare the local indication, buffered or recorder signal, alarm state and return to normal.

Which configuration record should accompany an installed 3300/35-05-02-01-00-00?
Record the complete model, 0–1000 °F scale, Pt100, α=0.00385, three-wire input, relay and barrier choices, channel assignments, setpoints, delays and the observed acceptance results.

Related Bently Nevada products

Bently Nevada 330101-24-35-10-02-00

Bently Nevada 170180-01-00

Bently Nevada 330130-070-00-CN

Bently Nevada 330101-23-38-10-02-00

Selection caution

Related links support product comparison only. Confirm input family, sensitivity, range, relay hardware, barriers and approvals for every alternative before selection.

Release criterion

Return the channel to service only after its measured response, output behavior and protection-state restoration agree with the approved machine configuration.