Bently Nevada 3300/16-02-01-00-00-00-01

01 Exact-model technical scope

Configuration represented by this reference

Bently Nevada 3300/16-02-01-00-00-00-01 is a 3300/16 XY/GAP Dual Vibration Monitor configured for 0–5 mils pp with 3300/3300 XL 8 mm or 7200 5/8 in, 200 mV/mil; its selected hardware provides no alarm relay outputs, a standard unbarriered input interface, no agency-approval option selected, 2X range multiplication. This reference treats the complete order code as one configuration; values from another range, input, relay or barrier variant are not transferred into this selection.

Selected technical configuration

Technical item	Selected value
Measurement function	XY or dual radial vibration with gap indication
Selected range	0–5 mils pp
Input system	3300/3300 XL 8 mm or 7200 5/8 in, 200 mV/mil
Signal sensitivity	200 mV/mil where specified by the selected input
Alarm relay option	None
Safety-barrier option	None
Agency approval option	None
Range multiplier	2X

Measurement boundaries

3300/16 XY/GAP Dual Vibration Monitor
The monitor family defines the processing architecture.

Range
0–5 mils pp is the selected display and alarm basis.

Input
3300/3300 XL 8 mm or 7200 5/8 in, 200 mV/mil is the required source configuration.

Outputs
None relay selection and the recorder or indication path must be assessed separately.

Use the complete code

A family number identifies the monitor function, but the remaining code groups determine the usable range and interfaces. Match the complete marking before changing a monitor, rear interface or field transducer.

Bently Nevada 3300/16-02-01-00-00-00-01

02 Signal path and selected options

Order-code selections

Selection	Configured choice
Measurement range	0–5 mils pp
Input / processing	3300/3300 XL 8 mm or 7200 5/8 in, 200 mV/mil
Alarm relay option	None
Safety-barrier option	None
Approval selection	None
Range multiplier	2X

Range and input form one conversion

The selected range is meaningful only when the connected input system and sensitivity agree with the monitor configuration. A stable value is not proof of correct scaling; apply a controlled signal change and compare the expected and displayed response.

Interface review

No relay option
Do not assume local alarm contacts are fitted.

Unbarriered path
Review the full loop before adding a barrier.

Approval boundary
No agency-approval option is selected in this code.

Range multiplication
2X multiplication must be included in scaling checks.

Check one channel at a time

Identify the source, monitor channel, local indication, recorder destination and alarm path before applying a test. A one-channel-at-a-time sequence exposes crossed wiring without relying on labels alone.

Bently Nevada 3300/16-02-01-00-00-00-01

03 Measurement use and application limits

Common applications

Orthogonal Shaft Vibration And Gap Monitoring
Apply the selected 0–5 mils pp span to the intended machine measurement.

Two-channel condition monitoring
Keep channel identity from the field transducer through indication and alarms.

Controlled maintenance testing
Inject or apply a known change and compare each response stage.

Protection-system integration
Verify the selected relay and barrier interface with the receiving circuit.

Technical evaluation sequence

01	Confirm the exact model and selected range.
02	Trace the intended transducer signal to its monitor input.
03	Apply a known change within the selected measurement span.
04	Compare local indication and the selected output path.
05	Restore the recorded settings and normal machine-protection state.

Acceptance observations

Configured item	Acceptance point
0–5 mils pp	Check the active span and units.
3300/3300 XL 8 mm or 7200 5/8 in, 200 mV/mil	Confirm source type, sensitivity and polarity.
None	Verify relay presence and contact behavior.
None	Confirm the corresponding field interface.
2X	Include the multiplier state in setpoint calculations.

Application boundary

The complete channel must preserve the transducer source, displayed range, relay interface and barrier selection together. A monitor from the same family can produce a plausible indication while applying a different scale or output arrangement.

Bently Nevada 3300/16-02-01-00-00-00-01

04 Technical questions for this exact model

Questions 1–4

Can 3300/16-02-01-00-00-00-01 use setpoints copied from a monitor with a different range?
The selected measurement span is 0–5 mils pp. Alarm and recorder scaling must be checked against that span rather than copied from a different range option.

How should the 3300/3300 XL 8 mm or 7200 5/8 in, 200 mV/mil source be checked before connecting 3300/16-02-01-00-00-00-01?
This configuration uses 3300/3300 XL 8 mm or 7200 5/8 in, 200 mV/mil. Preserve the transducer family, sensitivity and signal polarity as one measurement chain.

Does 3300/16-02-01-00-00-00-01 provide local alarm relay contacts?
No alarm relay hardware is selected; use the measurement and recorder interfaces without assuming local relay contacts.

Can a safety barrier be added to 3300/16-02-01-00-00-00-01 without reviewing the signal loop?
No safety-barrier option is selected. Do not move field conductors from a barrier-equipped circuit without an engineering review.

Core configuration values

Item	Value
Measurement range	0–5 mils pp
Input / processing	3300/3300 XL 8 mm or 7200 5/8 in, 200 mV/mil
Alarm relay option	None
Safety-barrier option	None

Interpret answers as a complete path

Each answer applies to this exact order code. Compare the selected transducer, monitor scale and physical machine condition at the same stable test point instead of treating any single reading as sufficient evidence.

Retain channel identity

Record which field source, display, recorder destination and alarm circuit belong together before any conductor is moved.

Bently Nevada 3300/16-02-01-00-00-00-01

05 Output, replacement and release questions

Questions 5–8

Why does a similar approved monitor not establish approval for 3300/16-02-01-00-00-00-01?
No agency-approval option is selected in this order code. Do not infer an approval from another unit in the same monitor family.

How should the 2X state be included in a 3300/16-02-01-00-00-00-01 recorder-output test?
The 2X multiplier expands the usable displayed range from the base scale. Confirm the multiplier state before comparing setpoints or recorder values.

Which functional test should precede return of 3300/16-02-01-00-00-00-01 to service?
Apply a controlled input change to one identified channel at a time, then compare the local indication, buffered or recorder signal, alarm state and return to normal.

Which technical settings should be recorded after commissioning 3300/16-02-01-00-00-00-01?
Record the complete model, 0–5 mils pp scale, 3300/3300 XL 8 mm or 7200 5/8 in, 200 mV/mil input, relay and barrier choices, channel assignments, setpoints, delays and the observed acceptance results.

Related Bently Nevada product references

Bently Nevada 80173-110-02

Bently Nevada 80173-110-01

Replacement boundary

Related monitors and transducers may use different ranges, sensitivities, power requirements, barrier arrangements or relay hardware. Review their complete codes independently before using them as replacements.

Final technical record

Use a controlled input condition to verify the 0–5 mils pp scale, 3300/3300 XL 8 mm or 7200 5/8 in, 200 mV/mil conversion, channel identity and selected output behavior. Restore the recorded alarm, delay, reset, multiplier and bypass states only after the complete path responds correctly.