NRED-61-E

01 / Identity and auxiliary-power role

ABB NRED-61-E is offered as a voltage adapter module for drive power-supply service. The NRED-61 base design connects the DC link to the power-supply path.

Preserve two levels of identification

Offered reference	NRED-61-E: retain the complete suffix and any additional label markings.
Base design	NRED-61: a thick-film hybrid voltage adapter in the DC-link-to-power-supply path.
Host-unit context	The base design concerns applicable 690 V AC drive units. This is a host class, not a standalone adapter input rating.

Before servicing the adapter

Record the installed unit, component label, connection positions and power-supply arrangement. Match the offered adapter to the controlled drive configuration before removing the original.

Work boundary

This guide supports preparation and inspection. Use the applicable ABB drive instructions for electrical isolation, discharge, connection details and testing.

Product and installation enquiries

sales13@apterpower.com | +86 18030235313

Apply manufacturer instructions and approved site procedures.

02 / Readiness and circuit identification

Complete marking	Match NRED-61-E and any revision or additional ABB identification against the installed unit.
Circuit position	Identify the DC-link side and the power-supply side using the applicable drive circuit documentation.
Connections	Record terminal positions, conductor routing and polarity before disturbing the component.
Physical condition	Inspect the body, terminals, mounting and nearby insulation for visible heat or mechanical damage.
Fault history	Review power-supply faults and any DC-link overvoltage event before deciding on a replacement.

Do not substitute by appearance

A similar body or connector arrangement does not establish equivalence. Preserve the full suffix and actual circuit relationship when selecting the replacement.

Avoid incorrect rating assumptions

Do not use the host-unit voltage class to infer resistance, clamping level, current capacity or an independent adapter input limit. Apply the controlled circuit requirements for the installed unit.

Product and installation enquiries

sales13@apterpower.com | +86 18030235313

Apply manufacturer instructions and approved site procedures.

03 / Controlled replacement workflow

1 / Establish isolation	Follow the drive shutdown, isolation and capacitor-discharge procedure. Verify the absence of hazardous voltage at the affected circuit.
2 / Record the original	Capture the full marking, mounting arrangement, terminal positions and conductor route.
3 / Inspect the affected path	Inspect the adapter, power supply and associated connections. Investigate abnormal heating or overvoltage history.
4 / Compare and install	Match the complete adapter identity and physical connection arrangement. Use the applicable mounting and wiring instructions.
5 / Review before power	Check connections, insulation, fastening and the surrounding work area before controlled energization.

Stored-energy boundary

The adapter is associated with the DC-link supply path. A stopped motor or inactive display does not prove that the relevant circuit is safe to touch.

Configuration record

Retain the original and replacement identities together with the drive service record. Document a changed part marking before returning the drive to service.

Product and installation enquiries

sales13@apterpower.com | +86 18030235313

Apply manufacturer instructions and approved site procedures.

04 / Acceptance and fault interpretation

Visual acceptance	Verify correct mounting, intact insulation and restored conductor routing before electrical checks.
Circuit acceptance	Compare the restored connection arrangement with the applicable drive documentation.
Controlled energization	Apply the drive commissioning sequence and check the affected auxiliary-power behavior.
Diagnostic review	Resolve power-supply or DC-link-related faults under the approved troubleshooting procedure.
Operational release	Keep the accepted results and complete adapter marking with the equipment maintenance file.

Overvoltage-related damage

An abnormal DC-link event can affect the adapter and associated power supply. Replacing a damaged component does not establish that the initiating fault has been corrected.

No generic test values

Use the circuit-specific test method and limits for the installed drive. An assumed resistance or clamping test from a different NRED version is not an acceptance criterion for NRED-61-E.

Product and installation enquiries

sales13@apterpower.com | +86 18030235313

Apply manufacturer instructions and approved site procedures.

05 / Maintenance decisions and references

Recurring supply fault	Review the adapter, associated power supply, conductor connections and DC-link event history together.
Different suffix or construction	Resolve the replacement identity against the installed configuration before proceeding.
Service planning	Use the actual drive maintenance plan and current manufacturer replacement guidance for the complete reference.

Technical basis

ABB ACS600 Main Circuit Control Boards, DOCMNACS60029 Rev. C, 27 June 2006; ABB ACN/ACW644+V991 Modules Installation Instruction, 3AFE 6896 2463 Rev. B.

Other ABB product references

ABB NDCU-11CK 64053868B

ABB GINT-6611C 68577349

ABB 1SFA664001R1001 TVOC-2-240

Portfolio navigation only. These products are not confirmed substitutes or included items for NRED-61-E.

Handover record

Retain label photos, the connection record, identified fault cause and accepted commissioning results.

Product and installation enquiries

sales13@apterpower.com | +86 18030235313

Apply manufacturer instructions and approved site procedures.