Bently Nevada 990-10-70-03-00

01 Function and selected configuration

Product function

Bently Nevada 990-10-70-03-00 brings radial shaft motion into the machinery controller through a powered current loop, while retaining a separate diagnostic connection for the probe signal.

Selected configuration

The selected configuration combines a 0-10 mils peak-to-peak measurement span, a 7.0 m transducer system and din clips and screws. The integrated proximity conditioner accepts one compatible 3300 NSv probe with its matched extension cable; the probe lead and extension together establish the calibrated length.

Functional path

NSv probe / shaft gap	Matched 7.0 m chain	990 conditioner	4-20 mA receiver

Measurement span	0-10 mils peak-to-peak
Transducer system	7.0 m, compatible 3300 NSv probe and cable
Mounting	DIN clips and screws

The two-wire loop supplies power and transmits peak-to-peak shaft vibration amplitude as 4-20 mA. The receiving control system supplies the alarm and protection logic. Non-interacting zero and span adjustments support loop calibration, while the TEST input accepts a AC signal generator for controlled output checks.

990-10-70-03-00

02 Technical operating envelope

Measurement	Radial vibration
Full-scale span	0-10 mils peak-to-peak
Electrical system length	7.0 m
Signal output	4-20 mA; two-wire
Terminal supply	+12 to +35 VDC
Maximum loop resistance	1000 ohms at 35 VDC; includes cable

Frequency response	5 Hz-6000 Hz; +0/-3 dB
Current limit	23 mA typical
Mounting	DIN clips and screws
Transmitter temperature	-35 to +85 degrees C
Fault current	Below 3.6 mA

Loop supply and burden apply at the transmitter terminals. Temperature and performance are conditional on the matched components; probe limits are not transmitter-body limits.

Signal interpretation

The 0-10 mils peak-to-peak range is the selected process-loop measurement. The separate dynamic output is a diagnostic signal, not a second isolated process loop.

Interface boundary

The 7.0 m electrical length belongs to probe plus extension. Loop wiring, diagnostic lead length and probe cable length are different constraints.

Can shortening the probe cable preserve the calibration of 990-10-70-03-00?

No. Its 7.0 m electrical length depends on the matched probe and extension cable. Altering that chain changes the transducer relationship.

990-10-70-03-00

03 System integration and applications

Machine-point signal conditioning

Convert one radial vibration measurement into a 4-20 mA input for the controller.

Calibrated loop renewal

Retain the 0-10 mils peak-to-peak receiver range and 7.0 m electrical chain when replacing the transmitter.

Probe-signal diagnosis

Observe the dynamic and gap signal with the specified diagnostic connection and instrument isolation.

Protection-loop verification

Use the TEST input with a AC signal generator to compare signal output and receiving indication.

System and supply context

990-10-70-03-00 connects a matched NSv probe and extension to a powered current-loop receiver. Probe, cable, test adapter and receiving control equipment are separate unless included in the quotation.

Application boundary

Use the 0-10 mils peak-to-peak scale for shaft-vibration supervision of the assigned machine point. Protective alarm logic remains in the receiving system.

What is the nominal current at half scale for 990-10-70-03-00?

For the proportional 4-20 mA loop, half scale corresponds to 12 mA and 5 mils peak-to-peak. Confirm the actual calibrated endpoints during loop verification.

990-10-70-03-00

04 Engineering selection decisions

Why must 990-10-70-03-00 use a different controller span from a 0-5 mil transmitter?

Its 0-10 mil peak-to-peak range is twice that span. A receiver left at 0-5 mil would under-report the same 4-20 mA fraction of full scale.

How should 990-10-70-03-00 be mounted when both clips and screws are supplied?

The 03 mounting option provides DIN clips and screws. Use the arrangement selected for the installation while keeping adjustment and wiring access clear.

How quickly does 990-10-70-03-00 recover after a corrected transducer fault?

Once the Not OK condition is removed, the signal is restored in approximately 2-3 seconds. Verify a stable recovery before restoring protection logic.

Where are alarms generated when 990-10-70-03-00 is installed?

Alarm thresholds and protective logic belong to the receiving control system. Check its 0-10 mil scaling, fault-current handling and configured setpoints together.

Keep test grounding controlled	The diagnostic connection is non-isolated.
Recognize Not OK	Distinguish below-3.6 mA fault and startup states from valid measurements.

990-10-70-03-00

05 Configuration boundary and references

Lifecycle and support

The current manufacturing and factory-support phase of 990-10-70-03-00 is not confirmed. Apter Power availability is assessed separately from manufacturer lifecycle status.

Replacement assessment

Match the 0-10 mils peak-to-peak scale, 7.0 m length, din clips and screws and supplied approval markings. Keep the receiver alarm scale with the measurement.

Document roles

Use the original manufacturer excerpt for its preserved technical tables and drawings. This product brief explains selection and system context. The separate installation guide covers preparation, connection, tests and handover; it does not replace manufacturer instructions.

Technical basis

Bently Nevada 990 Vibration Transmitter, 141612 Rev. Y.

Related product navigation

- Bently Nevada 990-05-XX-01-00 MOD:165335-01
- Bently Nevada 991-01-XX-02-05

These are related references, not confirmed substitutes or an automatically approved assembly.

Product enquiries