SPGU240A1

Installation Verification Guide | controlled replacement

A supply-board exchange affects the entire protection relay. Preserve the as-found auxiliary voltage, relay type and Uaux/supervision indications before isolation.

01 Capture the installed state

Verify supply selection
Measure and identify the site AC or DC auxiliary voltage before fitting the module.

Check the relay case
Compare host relay type, supply-module position and front-panel marking with the installed unit.

02 Prepare and fit the unit

Use specified fuse
Maintain the 1 A slow fuse type in the appropriate protection position.

Isolate before removal
Disconnect auxiliary supply and follow the relay service procedure before extracting the module.

03 Verify restoration

Inspect indications
Check the host Uaux indication and any self-supervision alarm after re-energization.

Test relay operation
Confirm the complete protection relay responds correctly under the approved site test plan.

Relay acceptance record

Auxiliary source	Record measured AC/DC type and nominal value.
Indication	Confirm Uaux and self-supervision behavior after energizing.
Protection function	Complete the approved relay checks before returning the circuit to service.

Enquiry contact

Apter Power | Technical enquiry
sales13@apterpower.com | +86 18030235313