Indramat REFU-RZB-01.2-UN

COMPLETE PRODUCT INFORMATION / EXACT-MODEL ENGINEERING FILE

Indramat REFU-RZB-01.2-UN is identified as a drive keypad display panel for the Indramat REFU drive operator-interface platform. The complete marking and installed interface arrangement must be matched before replacement.

01 Product overview

Identity control	Installed boundary	Acceptance record
Match every token in the complete REFU-RZB-01.2-UN marking.	Preserve connector orientation, cable ownership and host position before removal.	Retain diagnostics and controlled functional-test evidence with the maintenance record.

The complete REFU-RZB-01.2-UN marking identifies the offered drive keypad display panel. Record the removed item, host position and connected hardware so the comparison uses the actual installed boundary rather than a shortened family name.

Within the Indramat REFU drive operator-interface platform, evaluate REFU-RZB-01.2-UN together with its carrier, terminals, cables and applicable project or hardware settings. Preserve the as-found interface map and revision evidence; a mechanically similar item is not automatically equivalent.

Technical data

Complete order code	REFU-RZB-01.2-UN
Product type	Drive Keypad Display Panel

Related product references

- B&R 8V1022.001-2
- Fanuc A20B-3300-0281/04B
- General Electric IC695PNC001
- General Electric DS200TBCAG1AAB
- Hardy 1746-WS
- HMS AB5030-B
- ABB DO801 3BSE020510R1
- Bently Nevada 3300/47

Engineering record prompts

Nameplate record	Capture the complete marking, visible revision and installed position before removal.
Connector record	Photograph every used connector, cable label, keying feature and shield termination.
Host record	Identify the carrier, rack, drive, chassis or operator station that owns the installed position.
Configuration record	Archive the applicable project, address, parameter, firmware or hardware-setting evidence.
Supply-scope record	List terminal blocks, carriers, plugs, cables and accessories separately in the quotation.

02 Technical data and installed-system relationship

System context	Indramat REFU drive operator-interface platform
Panel family	REFU RZB

Engineering interpretation

Complete identity	Use REFU-RZB-01.2-UN as one complete reference in the quotation, service record and acceptance file.
Installed position	Record the exact host position and functional ownership within the Indramat REFU drive operator-interface platform.
Physical execution	Compare artwork, connectors, keying, terminal hardware and orientation with the removed assembly.
Configuration boundary	Preserve the applicable project, address, firmware or hardware-setting record before removal.
Acceptance evidence	Retain initial and as-left diagnostics plus the controlled functional-test result.
Unstated values	Do not assign electrical or compatibility values that are not established by the exact-model evidence.

Controller platform reference

Indramat REFU drive operator-interface platform. Confirm the exact installed execution and approved maintenance record.

Related product references

- General Electric IC695PNC001
- General Electric DS200TBCAG1AAB
- Hardy 1746-WS
- HMS AB5030-B
- ABB DO801 3BSE020510R1
- Bently Nevada 3300/47
- B&R 8V1022.001-2
- Fanuc A20B-3300-0281/04B

Engineering record prompts

Host record	Identify the carrier, rack, drive, chassis or operator station that owns the installed position.
Configuration record	Archive the applicable project, address, parameter, firmware or hardware-setting evidence.
Supply-scope record	List terminal blocks, carriers, plugs, cables and accessories separately in the quotation.
Baseline result	Record initial indications, diagnostics and the controlled-system condition before work.
Identity decision	Approve only the complete order code and observed execution; do not shorten the family name.

03 Applications / Compatibility

System position: REFU-RZB-01.2-UN is evaluated within the documented Indramat REFU drive operator-interface platform architecture. Compatibility boundary: Match the complete marking, hardware execution and installed interfaces before replacement.

Installed-system replacement
Compare the exact code, host position and connected interfaces with the removed item.

Planned maintenance
Capture the as-found label, indications and configuration before disturbing the installation.

Controlled commissioning
Restore documented connections and prove the intended signal, communication or control response.

Spare qualification
Keep revision, configuration and acceptance evidence with the spare-part record.

Product Precautions

Verify the complete identity
Check every token in REFU-RZB-01.2-UN against the offered label and approved record.

Isolate the work boundary
Follow the site procedure for stored energy, field power and electrostatic handling.

Record connections
Photograph and label carriers, terminals, cables and keying before removal.

Preserve configuration
Archive applicable Indramat REFU drive operator-interface platform settings before replacement.

Inspect mating hardware
Check connectors, terminal blocks, carriers and cable condition before blaming the module.

Prove the result
Use an approved functional test and retain as-left diagnostic and acceptance evidence.

Additional verified data

Execution	01.2-UN
Verification boundary	Match keypad layout, display, connector and host drive before replacement

Related product references

- Hardy 1746-WS
- HMS AB5030-B
- ABB DO801 3BSE020510R1
- Bently Nevada 3300/47
- B&R 8V1022.001-2
- Fanuc A20B-3300-0281/04B
- General Electric IC695PNC001
- General Electric DS200TBCAG1AAB

04 Technical FAQ

How should REFU-RZB-01.2-UN be identified before replacement?	Compare the complete REFU-RZB-01.2-UN marking, visible revision, installed position and the documented drive keypad display panel role. Do not approve a shortened family reference.
What evidence should be recorded before removing REFU-RZB-01.2-UN?	Photograph the complete label, connectors, cable routes, status indications and host position for REFU-RZB-01.2-UN; retain the current Indramat REFU drive operator-interface platform record.
How should the interfaces for REFU-RZB-01.2-UN be checked?	Map every connector, terminal and cable used by REFU-RZB-01.2-UN to the as-found record, then verify keying, shielding and interface ownership before reconnection.
What configuration boundary matters when commissioning REFU-RZB-01.2-UN?	Use the approved Indramat REFU drive operator-interface platform configuration for REFU-RZB-01.2-UN. Physical fit alone does not establish electrical, firmware or project equivalence.
How can a suspected REFU-RZB-01.2-UN fault be separated from an external fault?	Check host power, mating hardware, field wiring and the applicable signal or communication path before controlled substitution of REFU-RZB-01.2-UN.

Lifecycle Status

REFU-RZB-01.2-UN status	A current lifecycle phase for this complete order code has not been confirmed.
Support and replacement	Match the complete identity, hardware execution and installed configuration when planning service.
Apter Power availability	The offered quantity and dispatch date are confirmed in the quotation.

Alternative Names

Reference variant	Indramat REFU RZB 01.2 UN
Reference variant	REFU-RZB-01.2-UN Drive Keypad

Related product references

- Fanuc A20B-3300-0281/04B
- General Electric IC695PNC001
- General Electric DS200TBCAG1AAB
- Hardy 1746-WS
- HMS AB5030-B
- ABB DO801 3BSE020510R1
- Bently Nevada 3300/47
- B&R 8V1022.001-2

Engineering record prompts

Connector record	Photograph every used connector, cable label, keying feature and shield termination.
Host record	Identify the carrier, rack, drive, chassis or operator station that owns the installed position.

05 Ordering, downloads and enquiry workflow

What should be verified after installing REFU-RZB-01.2-UN?	Confirm normal indications, interface continuity and the intended drive keypad display panel response for REFU-RZB-01.2-UN in an approved test state.
Can REFU-RZB-01.2-UN be replaced by a similar-looking unit?	Appearance is not an equivalence criterion for REFU-RZB-01.2-UN; compare the complete order code, revision, connectors and installed configuration.
What handover record is appropriate after work on REFU-RZB-01.2-UN?	Retain the offered and removed REFU-RZB-01.2-UN markings, connection photographs, configuration evidence, diagnostics, functional-test results and open exceptions.

Ordering checks

Match the complete marking	Compare REFU-RZB-01.2-UN with the installed label and applicable Indramat documentation.
Check the offered item before ordering	Request photos of the offered REFU-RZB-01.2-UN and compare markings, interfaces and included items with the installed unit.

Technical notes

Evidence scope	The exact model is consistently identified as a drive keypad display panel; unsupported supply, display and communications values are not assigned.
Installation boundary	The exact installed carrier, terminals, cables and project configuration remain site-specific.
Technical reference	Complete supplied marking and exact-model replacement records

What happens after you enquire

Review your reference	Send the complete REFU-RZB-01.2-UN marking, quantity and installed-system context.
Confirm the offer	Review the offered identity, condition, included items and delivery details.
Arrange dispatch	Confirm the accepted quantity and destination in the quotation.

Related product references

General Electric DS200TBCAG1AAB

Hardy 1746-WS

HMS AB5030-B

ABB DO801 3BSE020510R1

Bently Nevada 3300/47

B&R 8V1022.001-2

Fanuc A20B-3300-0281/04B

General Electric IC695PNC001

Engineering record prompts

Configuration record	Archive the applicable project, address, parameter, firmware or hardware-setting evidence.

Discuss the complete REFU-RZB-01.2-UN marking with Apter Power.

sales13@apterpower.com | +86 18030235313

Scan the WhatsApp QR to share nameplate and installed-system evidence.