Bently Nevada 330909-00-65-05-02-00

Engineering Installation, Diagnostic and Acceptance Guide

Bently Nevada 330909-00-65-05-02-00 is a armored 3300 xl nsv proximity probe for restricted-clearance eddy-current measurements. This configuration uses 3/8-24 UNF-2A, a 6.5 in case and 0.5 m integral lead.

01 Work package

Complete model	330909-00-65-05-02-00
Product type	Armored 3300 XL NSv proximity probe
Manufacturer	Bently Nevada
Supply condition	New, original product
Technical source	Bently Nevada 3300 XL NSv Proximity Transducer System Datasheet, 147385 Rev. R

Field decisions

1 Establish identity

Capture the full marking, installed companion components and baseline before disconnection.

2 Inspect interfaces

Verify mounting, cable, connector, armor, approval and environmental boundaries.

3 Fit the exact chain

Preserve the documented probe-cable-Proximitor or sensor-monitor relationship.

4 Prove response

Use the approved stopped-machine and operating acceptance procedure.

5 Record as left

Save markings, configuration, test values and operating observations.

02 Interface and configuration map

Product type	Armored 3300 XL NSv proximity probe
Case thread	3/8-24 UNF-2A
Armor	Stainless-steel armor
Unthreaded length	0.0 in
Overall case length	6.5 in
Integral lead length	0.5 m
Connector	Miniature ClickLoc coaxial connector

Approval selection	No agency approval required
Matched-system linear range	1.5 mm under the stated target and calibration conditions
Matched-system scale factor	7.87 V/mm (200 mV/mil) under the stated conditions
Reference target	AISI 4140 steel unless the installation is separately characterized
Probe temperature range	-52 to +177 deg C
Proximitor operating range	-52 to +100 deg C
Probe tip material	Polyphenylene sulfide (PPS)
Integral cable	75 ohm triaxial cable with FEP insulation
System-length rule	Probe lead plus extension cable must match the selected 5 m or 7 m NSv Proximitor system

03 Installation workflow

Confirm the complete marking

Match every field of 330909-00-65-05-02-00 with the installed record before removal or installation.

Protect sensing and interfaces

Keep the sensing face, connector and cable free from impact, moisture, metal chips and unsupported loading.

Preserve the mechanical datum

Record reach, thread engagement, locknut position and target relationship before disturbing the installed component.

Control the cable route

Maintain approved bend radius, separation and strain relief; do not twist or crush the coaxial path.

Restore the operating point

Use the approved stopped-machine procedure and confirm expected target travel remains in the documented working region.

Prove the complete channel

Verify the as-left electrical reading, monitor indication and operating response before return to service.

Application checks

Radial shaft vibration

Use the approved bearing location and matched transducer chain to observe shaft motion relative to the probe mounting.

Axial position

Orient the probe toward a suitable conductive thrust target and keep expected travel inside the calibrated working region.

Speed or phase reference

Use an approved target feature and monitor configuration when the channel provides a once-per-turn reference.

Maintenance replacement

Preserve the exact mechanical identity, cable construction, system length and approval selection recorded for the installed channel.

04 Diagnostic decision table

Why is the restricted-space geometry important for 330909-00-65-05-02-00?	NSv was developed for small counterbores and sideview or rearview targets. Confirm tip access, target width and full travel before setting the final gap.
Which extension cable completes the installed chain for 330909-00-65-05-02-00?	Use the 0.5 m probe lead and the installed 5 m or 7 m NSv Proximitor identity to determine the required NSv extension cable; do not substitute 8 mm family cable.
How should the temperature boundary of 330909-00-65-05-02-00 be applied?	Separate probe and cable temperature capability from the lower Proximitor limit, and evaluate the actual temperature at each component rather than applying one rating to the entire route.
How can target geometry affect the response of 330909-00-65-05-02-00?	A narrow, curved or off-center target can change scale and linearity. Confirm the manufacturer target rules and prove the installed travel against the approved machine baseline.

Release review

Installation relationship	Use the 3/8-24 UNF-2A mounting and 0.0 in / 6.5 in geometry to establish the approved target relationship.
Temperature boundary	Apply probe, extension-cable and Proximitor temperature limits to their actual installed locations.
Technical reference	Bently Nevada 3300 XL NSv Proximity Transducer System Datasheet, 147385 Rev. R.

Engineering questions

Why is the restricted-space geometry important for 330909-00-65-05-02-00?	NSv was developed for small counterbores and sideview or rearview targets. Confirm tip access, target width and full travel before setting the final gap.
Which extension cable completes the installed chain for 330909-00-65-05-02-00?	Use the 0.5 m probe lead and the installed 5 m or 7 m NSv Proximitor identity to determine the required NSv extension cable; do not substitute 8 mm family cable.
How should the temperature boundary of 330909-00-65-05-02-00 be applied?	Separate probe and cable temperature capability from the lower Proximitor limit, and evaluate the actual temperature at each component rather than applying one rating to the entire route.
How can target geometry affect the response of 330909-00-65-05-02-00?	A narrow, curved or off-center target can change scale and linearity. Confirm the manufacturer target rules and prove the installed travel against the approved machine baseline.
How should the complete marking of 330909-00-65-05-02-00 be recorded before removal?	Photograph the full order identity, installed position, companion components and cable route. Save the stopped-machine baseline so the replacement can be returned to the same documented configuration.
Which compatibility check is most important before installing 330909-00-65-05-02-00?	Confirm that every companion component belongs to the documented 3300 XL NSv proximity transducer system. Connector fit alone does not establish electrical calibration or mechanical compatibility.
How should cable and connector integrity be tested for 330909-00-65-05-02-00?	Isolate the channel, inspect contacts for moisture, contamination and damage, verify continuity and insulation with an approved method, and support the cable so the connector carries no tensile load.
What commissioning evidence should be retained for 330909-00-65-05-02-00?	Retain full markings, mechanical datum, companion identities, wiring or chain-length checks, as-left measurements and the operating response accepted by the maintenance authority.

Acceptance and support

Retain the full marking, installed-chain identities, test readings and approved machine configuration. Confirm the exact offered item and included scope in the written quotation.

Discuss the exact marking and installed application with Apter Power.
sales13@apterpower.com | +86 18030235313

Verified related product references

Related product	330500-00-01
Related product	330980-70-CN
Related product	330930-040-03-00
Related product	84661-96

Commissioning record template

Installed asset	Machine, bearing, channel or cabinet reference
Companion identities	Probe, cable, sensor, interface or monitor markings
Mechanical datum	Mounting reference, reach, alignment or sealing condition
Electrical datum	Chain length, connector, shield, supply or input assignment
Before-work baseline	Gap, bias, vibration, continuity or channel observation
As-left result	Final measured value and functional proof
Approval basis	Applicable drawing, control requirement or site procedure
Handover	Technician, date, revision and maintenance-record location

Handover note

A replacement is complete only after the installed identity, physical interfaces, measured response and configuration record agree. Escalate any mismatch before the channel returns to protection or monitoring service.

Release checklist

Identity accepted	Complete marking agrees with the order, photographs and installed asset record.
Interfaces accepted	Mechanical fit, connector, wiring and companion components match the approved design.
Environment accepted	Temperature, contamination, vibration and route protection remain inside documented limits.
Configuration accepted	Hardware assignment, chain length or supply settings agree with the installed configuration.