ABB HITE303278R1

Procontic Control Module

ABB HITE303278R1 Procontic Control Module with verified technical identity, model-specific selection data and controlled commissioning guidance.

01 Product identity and selection data

Complete model	HITE303278R1
Product type	Procontic Control Module
Manufacturer	ABB
System / platform	ABB Procontic installed-base control systems

02 Exact-model technical capability map

Complete module reference	HITE303278R1
Associated board reference	IDB559B
Manufacturer	ABB
System family	Procontic installed base
Product class	Control module / printed circuit board
Installation format	Plug-in control-system board

Service boundary	Rack, slot, backplane and field interfaces
Configuration boundary	Installed application and signal assignments

03 Engineering role and selection boundary

Rack-controlled function
The board's active role is determined by its Procontic slot, backplane and application assignment.

Revision-sensitive replacement
Secondary markings and board revision are retained with the HITE303278R1 identity.

Database-led commissioning
Hardware recognition and assigned control functions are compared with the saved system baseline.

Exact marking
Approve the complete order reference only after the installed interfaces and companion hardware agree.

Technical basis	Exact-model installed-base records for ABB HITE303278R1 / IDB559B
Installed relationship	ABB Procontic installed-base control systems
Release gate	Resolve identity, interface and compatibility differences in the written offer before release.

04 Engineering overview and system application

HITE303278R1 is an ABB Procontic installed-base control module also recorded with board reference IDB559B. Available exact-model evidence establishes the identity and system class but does not justify unrelated modern interface claims.

Selection therefore relies on the complete front and rear markings, rack and slot, backplane connector and adjacent modules. The control database and signal assignments must be exported before the board is disturbed.

Use grounded ESD handling during exchange. Recommission by confirming rack recognition, stable diagnostics and representative assigned functions without altering the approved application.

Application map

Procontic control-rack service
Restore the documented board in its approved slot and backplane.

Legacy control-system maintenance
Preserve database, signal assignments and adjacent-module relationships.

Board-level fault isolation
Separate power, backplane, connector and application causes.

Exact-model spare planning
Match HITE303278R1, IDB559B and all revision labels.

Lifecycle and available-unit boundary

Lifecycle status	Legacy installed-base module
Supply scope	the HITE303278R1 procontic control module; companion hardware only when itemized
Dispatch	Swift global dispatch
Selection basis	Complete marking, installed relationship and written quotation

Technical notes and evidence boundary

Exact identity	HITE303278R1
Documented function	Procontic Control Module
Technical evidence	Exact-model installed-base records for ABB HITE303278R1 / IDB559B
Evidence boundary	Only the documented ABB Procontic installed-base control systems relationship and stated exact-model values are applied
Commissioning record	Retain installed markings, configuration and functional proof

Additional verified exact-model data

Evidence scope	No adjacent-model value is applied without a documented exact-model relationship.

05 Installation and product precautions

Back up the database
Export the Procontic application and assignments.

Record the full board identity
Capture HITE, IDB and revision markings.

Use ESD protection
Handle the PCB only under grounded controls.

Inspect the rack
Check slot, backplane and adjacent modules.

Start with recognition
Verify diagnostics before enabling field functions.

Test actual assignments
Compare representative operation with the baseline.

Controlled verification sequence

01 Record	Send the complete HITE303278R1 marking, revision labels, current-unit photographs and installed position.
02 Isolate	Apply the approved isolation and prove the safe state before disturbing the installed arrangement.
03 Compare	Reconcile the complete marking, interfaces, companion hardware and approved system record.
04 Prove	Compare the offered HITE303278R1 interfaces, ratings and included items with the approved system record before ordering.
05 Handover	Retain photographs, settings, readings, diagnostics and accepted deviations.

Engineering decision questions

Which secondary marking should be recorded with HITE303278R1?
Exact-model records associate HITE303278R1 with IDB559B; retain both markings and every revision label.

How should the rack position of HITE303278R1 be documented?
Photograph cabinet, rack, slot, backplane connector and adjacent modules before removal.

Which system records must be protected before replacing HITE303278R1?
Back up the Procontic application, signal assignments, parameters and active version.

What ESD controls apply to HITE303278R1?
Use grounded handling and antistatic packaging and protect board edges and connector contacts.

Verified related product pages

Recommended product	ABB PM511V16 3BSE011181R1
Recommended product	ABB F4332D 3HAC024322-001
Recommended product	ABB 170M5388/PC72UD13C250T 3AUA0000090404
Recommended product	ABB 170M6467 3AUA0000062487

Discuss the complete marking and installed application with Apter Power

sales13@apterpower.com | +86 18030235313

Scan the approved QR code for direct contact and quotation support.