

T9110

AADvance Processor Module

Installation and Verification Scope

This Apter Power field reference applies only to the complete ICS Triplex T9110 identification and the product type stated above.

Controlled Installation Checks

1. Confirm the exact order code, physical nameplate and hardware revision.
2. Confirm the approved chassis or base, slot keying and termination hardware.
3. Isolate power under the site safety procedure before removal or wiring work.
4. Verify field supply, polarity, shield, grounding and documented environmental limits.
5. Restore the controlled application and configuration, then complete diagnostics and functional tests before service.

Official Basis

Rockwell Automation ICSTT-RM448N-EN-P

https://literature.rockwellautomation.com/idc/groups/literature/documents/rm/icstt-rm448_-en-p.pdf

Apter Power - Industrial Automation Support

Sales: sales13@apterpower.com

WhatsApp / Phone: +86 180 3023 5313

Web: www.apterpower.com

Request the exact model, revision and nameplate.

