TC520 3BSE001449R1

Installation Verification Guide | controlled replacement

Status collection must be restored in the actual Advant Master rack. Record the fitted location, adjacent modules and current diagnostic state before service.

01 Capture the installed state

Record the original module
Photograph the full TC520 marking, installed position and surrounding connectors before removal.

Preserve diagnostic state
Capture system alarms and controller diagnostics so the service result can be compared.

02 Prepare and fit the unit

Identify the host rack
Match the actual AC 450 or AC 460 hardware arrangement to the project documentation.

Protect connectors
Follow site isolation and electrostatic-discharge procedures while handling the module.

03 Verify restoration

Restore the same arrangement
Reinstall only after checking mating hardware, slot and revision compatibility.

Prove the status path
Run the approved functional test and compare status changes and alarm behavior with the baseline.

Status acceptance record

Rack position	Record slot and surrounding modules.
Diagnostic baseline	Save pre-change alarm and status data.
Return to service	Verify the affected status path in the host system.

Enquiry contact

Apter Power | Technical enquiry
sales13@apterpower.com | +86 18030235313