

21500-00-12-10-02

Industrial Monitoring Component

Bently Nevada 21500-00-12-10-02 is an industrial monitoring component identified by the complete order code shown on the installed item and service record.

BRAND	Bently Nevada	ORIGIN	USA
MODEL	21500-00-12-10-02	FAMILY	Bently Nevada machinery monitoring

MANUFACTURER SOURCE RECORD

Bently Nevada Product Support
Baker Hughes / Bently Nevada product support

APTER POWER SALES TEAM

WHATSAPP / PHONE +86 180 3023 5313
EMAIL sales13@apterpower.com
WEBSITE www.apterpower.com



21500-00-12-10-02

Product Overview

SYSTEM FUNCTION

Bently Nevada 21500-00-12-10-02 is an industrial monitoring component identified by the complete order code shown on the installed item and service record.

PRESERVES THE COMPLETE ORDER IDENTITY

Verified model-specific feature or controlled record item.

SUPPORTS PHYSICAL-MARKING VERIFICATION

Verified model-specific feature or controlled record item.

SUPPORTS AS-FOUND CONNECTION DOCUMENTATION

Verified model-specific feature or controlled record item.

SUPPORTS CONTROLLED FUNCTIONAL ACCEPTANCE

Verified model-specific feature or controlled record item.

TECHNICAL NOTE

Record the full 21500-00-12-10-02 marking, installed position, mating hardware, cable and termination details before disturbance. Obtain Bently Nevada confirmation before substitution or recommissioning.

Technical Data and Acceptance

Acceptance Path

PARAMETER	VERIFIED VALUE
Manufacturer	Bently Nevada
Order identity	21500-00-12-10-02

1 IDENTITY

Record 21500-00-12-10-02.

2 INTERFACE

Document mounting and connections.

3 CONFIGURATION

Confirm system and channel.

4 PROOF

Complete functional acceptance.

ENGINEERING BOUNDARY

Use the exact ordering-code values shown here together with the physical marking and installed-system record. Confirm mounting, connections and the configured channel before release.

Applications and Precautions

INSTALLED-BASE MAINTENANCE

Maintains a controlled record for the exact installed order identity.

PLANNED REPLACEMENT VERIFICATION

Supports manufacturer confirmation before any substitute is accepted.

OUTAGE INSPECTION RECORDS

Captures mounting, cabling and termination evidence before disturbance.

CONTROLLED RECOMMISSIONING

Links restored identity and connections to the final functional test.

Controlled Checks

NO.	CHECK
1	Verify 21500-00-12-10-02 from the physical marking before work.
2	Do not infer dimensions, electrical values or approvals from a nearby model.
3	Photograph and record the installed position and mating hardware before removal.
4	Label every conductor, connector and cable route before disconnection.
5	Ask Bently Nevada support to confirm any proposed replacement or compatibility claim.
6	Restore the documented arrangement and complete a controlled functional test before release.

FAQ, Related Products and Source

QUESTION	ANSWER
What order-code verification is required for 21500-00-12-10-02?	Use the full order code on the physical item and the purchase record.
What installed-position record is required for 21500-00-12-10-02?	Record the exact equipment location and orientation before removal.
What termination mapping is required for 21500-00-12-10-02?	Create a conductor and terminal map before disconnecting the item.
What hardware control is required for 21500-00-12-10-02?	Retain the mounting and mating-hardware details with the service record.
What manufacturer review is required for 21500-00-12-10-02?	Ask Bently Nevada to confirm replacement suitability before substitution.
What configuration preservation is required for 21500-00-12-10-02?	Record the associated rack, module or channel configuration before work.
What return-to-service proof is required for 21500-00-12-10-02?	Confirm restored connections, diagnostics and controlled function before release.
What origin entry is required for 21500-00-12-10-02?	The current publishing instruction specifies USA.

Related Bently Nevada Products

MODEL	RELATION	APTER POWER PAGE
330104-00-22-10-02-00	Bently Nevada machinery-monitoring component	View 330104-00-22-10-02-00
330180-90-00	Bently Nevada machinery-monitoring component	View 330180-90-00
330101-00-53-10-12-05	Bently Nevada machinery-monitoring component	View 330101-00-53-10-12-05
330101-00-16-05-11-05	Bently Nevada machinery-monitoring component	View 330101-00-16-05-11-05
330101-30-60-10-02-05	Bently Nevada machinery-monitoring component	View 330101-30-60-10-02-05
330101-00-60-10-02-00	Bently Nevada machinery-monitoring component	View 330101-00-60-10-02-00
330101-00-26-05-01-05	Bently Nevada machinery-monitoring component	View 330101-00-26-05-01-05
330101-00-49-90-12-05	Bently Nevada machinery-monitoring component	View 330101-00-49-90-12-05

MANUFACTURER SOURCE RECORD

Bently Nevada Product Support
Baker Hughes / Bently Nevada product support

APTER POWER SALES TEAM

WHATSAPP / PHONE +86 180 3023 5313
EMAIL sales13@apterpower.com
WEBSITE www.apterpower.com



21500-00-12-10-02