


X20AI2632

Two-Channel Analog Input Module

CONTROLLED ENGINEERING COPY

B&R X20AI2632 is a two-channel analog input module for the documented X20 System installation.

INSTALLATION IDENTITY	REQUIRED VALUE
Complete model	X20AI2632
Manufacturer	B&R
System family	X20 System
HS code	8537101190
Shipping origin	Xiamen,Fujian,China



APTER POWER SALES TEAM

WHATSAPP / PHONE +86 180 3023 5313

EMAIL sales13@apterpower.com

WEBSITE www.apterpower.com

01 PRE-INSTALLATION PLAN

1

Confirm the complete B&R X20AI2632 marking and installed X20 System position before work.

2

Place the machine or process in the approved maintenance state and isolate every applicable energy source.

3

Record two voltage or current input channels and X20TB06/X20TB12, terminal assignments, shielding and protective-ground connections before removal.

4

Use ESD controls and protect keyed connectors, terminals and exposed electronics from contamination.

5

Verify analog inputs (2) against the installed project and connected hardware.

MATCHED HARDWARE

- X20AI2632 with complete identity
- X20 I/O station
- two voltage or current input channels and X20TB06/X20TB12
- Controlled commissioning and acceptance record

INSTALLATION CONTROL RECORD

CONTROL ITEM	REQUIRED RECORD
Identity	X20AI2632 recorded
Physical interface	Probe, cable and sensor matched
Functional proof	Static gap and dynamic response

02 WIRING & INTERFACE CHECKS

CHECK ITEM	REQUIRED VALUE
Analog inputs	2
Signal ranges	+/-10 V or 0 to 20 mA
Converter resolution	16 bit
Isolation	Channels isolated from bus
Channel isolation	Channels not isolated from each other
Bus module	X20BM11
Terminal block	X20TB06 or X20TB12
Protection	IP20
Pitch	12.5 mm


FIELD NOTE

Confirm B&R X20AI2632, X20 I/O station, two voltage or current input channels and X20TB06/X20TB12, wiring, grounding, configuration, companion accessories and controlled commissioning results before service release.

RELATED APTER POWER PAGES

[330708-00-10-90-02-00](#)[330103-00-12-10-12-05](#)[330104-10-15-10-01-05](#)[330101-00-16-05-11-05](#)[330105-02-12-90-12-00](#)[330130-045-00-00](#)[330106-05-30-05-02-00](#)[330101-00-10-10-01-05](#)

03 COMMISSIONING WORKFLOW



COMMISSIONING ACCEPTANCE EVIDENCE

EVIDENCE ITEM	ACCEPTANCE CONDITION
Identity	X20AI2632
Physical interface	two voltage or current input channels and X20TB06/X20TB12 matched
Configuration	Exact installed configuration and assignments restored
Functional proof	Controlled two-channel analog signal acquisition response recorded

04 RETURN-TO-SERVICE RECORD

- ☐
- Verify analog inputs (2) against the installed project and connected hardware.

☐☐☐

VERIFICATION RECORD

PRODUCT IDENTITY	X20AI2632
INSTALLED POSITION	Documented X20 I/O station position
VERIFICATION METHOD	Controlled inspection and functional test
RELEASE RECORD	Final diagnostic state retained before service

FUNCTIONAL ACCEPTANCE CHECKLIST

- ☐
- Confirm the exact model remains assigned to the documented host position.

☐☐☐

SOURCE IDENTIFIERS

B&R X20AI2632 product data | Data sheet X20AI2632