

0007	7 feet (2.1 meters)
0010	10 feet(3.0 meters)
0025	25 feet (7.6 meters)
0050	50 feet (15.2 meters)
0100	100 feet (30.5 meters)

B: Assembly Instructions

01	Not assembled
02	Assembled

Spares

176449-01	3500/40M Proximitor Monitor
125680-01	Proximitor I/O Module with Internal Terminations
126615-01	Proximitor I/O Module with External Terminations
135489-04	Proximitor I/O Module with Internal Barriers and Internal Terminations
143488	3500/40M Monitor User Guide
00580434	Internal I/O Module connector header, Euro style, 8-pin
00502133	Internal I/O Module connector header, Euro style, 12-pin
166M4363	Connector header, push-in-spring type (alternative for PN 00580441)
166M2389	Connector header, push-in-spring type (alternative for PN 00580434)