

MANUFACTURER-SOURCE TECHNICAL REFERENCE

Emerson A6312-06

A6312-06 Evidence-Bounded Product Information Manual

Emerson dual-channel speed and key monitor requested-label configuration

DOCUMENT SCOPE

Independent Apter Power manual compiled only from the cited Emerson manufacturer sources. No product photograph is included.

Product / lookup identity	Emerson A6312-06
Reference number	A6312/06
Document basis	Published Emerson product records, PDFs, and manuals listed on page 3



Product page

<https://www.apterpower.com/Emerson/a6312-06>

Apter Power contact

sales13@apterpower.com | +86 180 3023 5313

Workflow and system context

Emerson A6312-06 is an evidence-bounded dual-channel speed and key monitor requested-label configuration in the Emerson installed-base context. System role: The verified A6312 base monitors speed, phase/key, zero-speed and direction in IMR 6000/10 and 6000/30 systems.

- | | |
|----|--|
| 01 | System Inputs: The verified A6312 base monitors speed, phase/key, zero-speed and direction in IMR 6000/10 and 6000/30 systems. |
| 02 | Processing: Only base A6312 facts are published. The physical label must prove that A6312-06 or A6312/06 is the installed order/revision notation before configuration or replacement. |

Published context and boundaries

- | | |
|----|--|
| 01 | Verify the complete Emerson A6312-06 nameplate, revision and installed-system documentation before use. |
| 02 | Keep A6312-06 distinct from the explicitly documented A6312-8 8TE AMS 6500 version; do not infer suffix equivalence. |
| 03 | Current formal lifecycle phase, origin, HS code, dimensions and logistics weight remain HOLD without exact Emerson evidence. |

Verification and release checks

01	Verify the complete Emerson A6312-06 nameplate, revision and installed-system documentation before use.
02	Keep A6312-06 distinct from the explicitly documented A6312-8 8TE AMS 6500 version; do not infer suffix equivalence.
03	De-energize and follow the site's approved electrical and process-safety procedure before disturbing hardware or field wiring.
04	Back up controller, network, I/O, addressing and configuration data before replacement or firmware work.
05	Verify every companion module, termination unit, cable, connector and power source from approved drawings.
06	Do not copy electrical, communication, mechanical or lifecycle values from a related model or successor.

Identity and release controls

Verification Status	Base Model Verified Suffix Mapping Hold
---------------------	---

Official Emerson sources

Emerson Protection Cards Classic reference	https://www.emerson.com/is/content/emerson/en/systems-and-software/ams/manuals-and-guides/documents/6500_ref_protectioncardsclassic.pdf
--	---