

MANUFACTURER-SOURCE TECHNICAL REFERENCE

Emerson FX-340 960133-01

FX-340 960133-01 Evidence-Bounded Product Information Manual

Emerson requested legacy automation product identity

DOCUMENT SCOPE

Independent Apter Power manual compiled only from the cited Emerson manufacturer sources. No product photograph is included.

Product / lookup identity	Emerson FX-340 960133-01
Reference number	960133-01
Document basis	Published Emerson product records, PDFs, and manuals listed on page 3



Product page

<https://www.apterpower.com/Emerson/fx-340>
Apter Power contact

sales13@apterpower.com | +86 180 3023 5313

Workflow and system context

Emerson FX-340 960133-01 is an evidence-bounded requested legacy automation product identity in the Emerson installed-base context. System role: All functional, electrical, motion-control and host-system claims remain HOLD until the physical label and an Emerson order or service record are obtained.

- | | |
|----|--|
| 01 | System Inputs: All functional, electrical, motion-control and host-system claims remain HOLD until the physical label and an Emerson order or service record are obtained. |
| 02 | Processing: Preserve the existing /Emerson/fx-340 canonical and use this page as a source-traceable identity-verification record only. |

Published context and boundaries

- | | |
|----|--|
| 01 | Verify the complete Emerson FX-340 960133-01 nameplate, revision and installed-system documentation before use. |
| 02 | Do not publish third-party servo-drive descriptions, electrical ratings, dimensions, weight, origin, tariff or lifecycle as Emerson facts. |
| 03 | Current formal lifecycle phase, origin, HS code, dimensions and logistics weight remain HOLD without exact Emerson evidence. |

Verification and release checks

01	Verify the complete Emerson FX-340 960133-01 nameplate, revision and installed-system documentation before use.
02	Do not publish third-party servo-drive descriptions, electrical ratings, dimensions, weight, origin, tariff or lifecycle as Emerson facts.
03	De-energize and follow the site's approved electrical and process-safety procedure before disturbing hardware or field wiring.
04	Back up controller, network, I/O, addressing and configuration data before replacement or firmware work.
05	Verify every companion module, termination unit, cable, connector and power source from approved drawings.
06	Do not copy electrical, communication, mechanical or lifecycle values from a related model or successor.

Identity and release controls

Verification Status	Identity Verification Only
---------------------	----------------------------

Official Emerson sources

Emerson support and document verification entry point	https://www.emerson.com/en-us/support
---	---