

MANUFACTURER-SOURCE TECHNICAL REFERENCE

ABB NTCS04

NTCS04 Evidence-Bounded Product Information Manual

ABB NTCS04 communication-module termination unit

DOCUMENT SCOPE

Independent Apter Power manual compiled only from the cited ABB manufacturer sources. No product photograph is included.

Product / lookup identity	ABB NTCS04
Reference number	NTCS04
Document basis	Published ABB product records, PDFs, and manuals listed on page 3

**Product page**<https://www.apterpower.com/ABB/ntcs04>**Apter Power contact**

sales13@apterpower.com | +86 180 3023 5313

Workflow and system context

ABB NTCS04 is an evidence-bounded communication-module termination unit in the Bailey INFI 90 / Harmony Rack installed-base context. System role: It is the termination boundary for those supported communication modules.

- | | |
|----|--|
| 01 | System Inputs: It is the termination boundary for those supported communication modules. |
| 02 | Processing: The catalog does not make NTCS04 a generic serial or network termination unit; exact ports, cables and signal settings remain module/project-specific. |

Published context and boundaries

- | | |
|----|--|
| 01 | Verify the complete ABB NTCS04 nameplate, revision and installed-system documentation before use. |
| 02 | Keep NTCS04 distinct from NTCL01, NTMP01 and other communication termination units. |
| 03 | Current formal lifecycle phase, origin, HS code, dimensions and logistics weight remain HOLD without exact ABB evidence. |

Verification and release checks

01	Verify the complete ABB NTCS04 nameplate, revision and installed-system documentation before use.
02	Keep NTCS04 distinct from NTCL01, NTMP01 and other communication termination units.
03	De-energize and follow the site's approved electrical and process-safety procedure before disturbing hardware or field wiring.
04	Back up controller, network, I/O, addressing and configuration data before replacement or firmware work.
05	Verify every companion module, termination unit, cable, connector and power source from approved drawings.
06	Do not copy electrical, communication, mechanical or lifecycle values from a related model or successor.

Identity and release controls

Verification Status	Verified Exact Model Function
---------------------	-------------------------------

Official ABB sources

ABB Ability Symphony Plus Product Catalog	https://library.e.abb.com/public/67f6b20f64d0443da36258e62a597791/2VAA005340%20en%20G%20Symphony%20Plus%20Product%20Catalog.pdf
---	---