

MANUFACTURER-SOURCE TECHNICAL REFERENCE

Siemens C98043-A7105-L4-9

C98043-A7105-L4-9 Requested-Label Verification Evidence-Bounded Product Information Manual

Siemens requested SINAMICS DCM power-interface board revision

DOCUMENT SCOPE

Independent Apter Power manual compiled only from the cited Siemens manufacturer sources. No product photograph is included.

Product / lookup identity	Siemens C98043-A7105-L4-9
Reference number	C98043-A7105-L4-9
Document basis	Published Siemens product records, PDFs, and manuals listed on page 3



Product page

<https://www.apterpower.com/Siemens/c98043-a7105-l4-9-configuration-verification>
Apter Power contact

sales13@apterpower.com | +86 180 3023 5313

Workflow and system context

Siemens C98043-A7105-L4-9 is an evidence-bounded requested SINAMICS DCM power-interface board revision.
System role: The verified base board is the power-interface module used in the documented 4Q SINAMICS DCM architecture.

- | | |
|----|--|
| 01 | System Inputs: The verified base board is the power-interface module used in the documented 4Q SINAMICS DCM architecture. |
| 02 | Processing: Match converter order number, rated voltage/current, 4Q topology, option package, board label and complete hardware revision before replacement. |

Published context and boundaries

- | | |
|----|---|
| 01 | Verify the complete Siemens C98043-A7105-L4-9 physical label and installed-system documentation before use. |
| 02 | Do not treat the -9 suffix as an ordering number or copy compatibility from L1, L410, L440, L4-8 or other A7105/A7106/A7107/A7108 variants. |
| 03 | Origin and HS code remain unpublished unless an exact manufacturer record or the physical package label establishes them. |

Verification and release checks

01	Verify the complete Siemens C98043-A7105-L4-9 label, revision and installed-system documentation before use.
02	Do not treat the -9 suffix as an ordering number or copy compatibility from L1, L410, L440, L4-8 or other A7105/A7106/A7107/A7108 variants.
03	De-energize the equipment and follow the site's approved electrical and process-safety procedure before disturbing hardware or wiring.
04	Back up controller, drive, network and configuration data before replacement, migration or firmware work.
05	Verify every companion module, cable, connector, termination and power source from approved drawings.
06	Do not copy electrical, communication, mechanical or lifecycle values from a related model or successor.

Identity and release controls

Verification Status	Requested Revision Base Board Verified
---------------------	--

Official Siemens sources

SINAMICS DCM Fault Diagnostics	https://cache.industry.siemens.com/dl/files/847/40863847/att_940299/v1/FAQ_6RA80_Fault_Diagnostics_EN_V1.4_2018-1.pdf
SINAMICS DCM Base Drive Manual	https://support.industry.siemens.com/cs/attachments/109749923/SINAMICS_DCM_Standard_Range_15-1200A_DC_Base_Drive_Manual_4-11-2017.pdf