

MANUFACTURER-SOURCE TECHNICAL REFERENCE

Honeywell FC-BKM-0001 V1.1

FC-BKM-0001 V1.1 Evidence-Bounded Product Information Manual

Honeywell Safety Manager battery and key-switch module

DOCUMENT SCOPE

Independent Apter Power manual compiled only from the cited Honeywell manufacturer sources. No product photograph is included.

Product / lookup identity	Honeywell FC-BKM-0001 V1.1
Reference number	FC-BKM-0001
Document basis	Published Honeywell product records, PDFs, and manuals listed on page 3



Product page

<https://www.apterpower.com/Honeywell/fc-bkm-0001>

Apter Power contact

sales13@apterpower.com | +86 180 3023 5313

Workflow and system context

Honeywell FC-BKM-0001 V1.1 is an evidence-bounded Safety Manager battery and key-switch module. System role: It provides the documented battery/key-switch hardware function within a Safety Manager configuration.

- | | |
|----|---|
| 01 | System Inputs: It provides the documented battery/key-switch hardware function within a Safety Manager configuration. |
| 02 | Processing: Use only with the exact host, terminal base, cable, firmware and engineering configuration documented for the installed system. |

Published context and boundaries

- | | |
|----|---|
| 01 | Verify the complete Honeywell FC-BKM-0001 V1.1 physical label and installed-system documentation before use. |
| 02 | V1.1 is a physical revision marking; verify the complete module label and Safety Manager release before replacement. |
| 03 | Origin and HS code remain unpublished unless an exact manufacturer record or the physical package label establishes them. |

Verification and release checks

01	Verify the complete Honeywell FC-BKM-0001 V1.1 label, revision and installed-system documentation before use.
02	V1.1 is a physical revision marking; verify the complete module label and Safety Manager release before replacement.
03	De-energize the equipment and follow the site's approved electrical and process-safety procedure before disturbing hardware or wiring.
04	Back up controller, drive, network and configuration data before replacement, migration or firmware work.
05	Verify every companion module, cable, connector, termination and power source from approved drawings.
06	Do not copy electrical, communication, mechanical or lifecycle values from a related model or successor.

Identity and release controls

Verification Status	Verified Evidence Bounded
---------------------	---------------------------

Official Honeywell sources

Honeywell Safety Manager Hardware Reference	https://process.honeywell.com/us/en/products/process-automation/safety-systems/safety-manager
---	---