

MANUFACTURER-SOURCE TECHNICAL REFERENCE

Bently Nevada 21747-00-20-10-02

21747-00-20-10-02 Requested-Label Verification Evidence-Bounded Product Information Manual

Baker Hughes / Bently Nevada requested 7200 Series 21747 label requiring order-structure verification

DOCUMENT SCOPE

Independent Apter Power manual compiled only from the cited Baker Hughes / Bently Nevada manufacturer sources. No product photograph is included.

Product / lookup identity	Bently Nevada 21747-00-20-10-02
Reference number	21747-00-20-10-02
Document basis	Published Baker Hughes / Bently Nevada product records, PDFs, and manuals listed on page 3



Product page

<https://www.apterpower.com/Bently-Nevada/21747-00-20-10-02>

Apter Power contact

sales13@apterpower.com | +86 180 3023 5313

Workflow and system context

Bently Nevada 21747-00-20-10-02 is an evidence-bounded requested 7200 Series 21747 label requiring order-structure verification. System role: Publish only the requested label and verified 7200 family boundary; do not decode 00-20-10-02 as probe fields.

- | | |
|----|---|
| 01 | System Inputs: Publish only the requested label and verified 7200 family boundary; do not decode 00-20-10-02 as probe fields. |
| 02 | Processing: Use only with the exact host, terminal base, cable, firmware and engineering configuration documented for the installed system. |

Published context and boundaries

- | | |
|----|---|
| 01 | Attached-source boundary: Customer-supplied Bently Nevada 7200 Proximity Transducer Systems Technical/Ordering Information scan, pages 1-9 through 1-12; SHA-256 103C75CDE3B14A1250F5E5ID9CF5A457BD907D96252CBC146D9B22A671F43709. The scan is used only for the printed 7200 ordering table and system-level specifications. |
| 02 | Verify the complete Bently Nevada 21747-00-20-10-02 physical label and installed-system documentation before use. |
| 03 | Require the physical nameplate or Baker Hughes legacy order record before assigning length, armor, connector or probe characteristics. |

Verification and release checks

01	Verify the complete Bently Nevada 21747-00-20-10-02 label, revision and installed-system documentation before use.
02	Require the physical nameplate or Baker Hughes legacy order record before assigning length, armor, connector or probe characteristics.
03	De-energize the equipment and follow the site's approved electrical and process-safety procedure before disturbing hardware or wiring.
04	Back up controller, drive, network and configuration data before replacement, migration or firmware work.
05	Verify every companion module, cable, connector, termination and power source from approved drawings.
06	Do not copy electrical, communication, mechanical or lifecycle values from a related model or successor.

Identity and release controls

Verification Status	Requested Label Verification
---------------------	------------------------------

Official Baker Hughes / Bently Nevada sources

Bently Nevada Technical Documentation	https://www.bakerhughes.com/bently-nevada/technical-documentation
---------------------------------------	---