

MANUFACTURER-SOURCE TECHNICAL REFERENCE

ABB BP03 7760052242

BP03 7760052242 Label Verification Product Information Manual

ABB BP03 7760052242 Label Verification Official-Source Product Reference

DOCUMENT SCOPE

Independent Apter Power manual compiled only from the cited ABB manufacturer sources. No product photograph is included.

Product / lookup identity	ABB BP03 7760052242
Reference number	7760052242
Document basis	Published ABB product records, PDFs, and manuals listed on page 3



Product page

<https://www.apterpower.com/ABB/bp03-7760052242-label-verification>
Apter Power contact

sales13@apterpower.com | +86 180 3023 5313

Workflow and system context

ABB BP03 7760052242 is an evidence-bounded SPS03 power-system requested-label and base-unit verification reference in the ABB SPS03 and DCS power-system installed-base architecture context. System role: Use this page to verify whether the physical BP03 item is a power-distribution or base-unit component in the installed SPS03/DCS assembly before service work.

- | | |
|----|---|
| 01 | System Inputs: Use this page to verify whether the physical BP03 item is a power-distribution or base-unit component in the installed SPS03/DCS assembly before service work. |
| 02 | Processing: Power input, output rails, connectors, base-unit position and companion supply relationships must come from the exact manual revision and site wiring drawings. |

Published context and boundaries

- | | |
|----|---|
| 01 | Verify the complete ABB BP03 7760052242 nameplate, revision and installed-system documentation before use. |
| 02 | BP03 is not a unique global ABB key. Do not infer voltage, current, backplane function, compatibility or replacement from another BP03 designation. |
| 03 | Current formal lifecycle phase, origin, HS code, dimensions and logistics weight remain HOLD without exact ABB evidence. |

Verification and release checks

01	Verify the complete ABB BP03 7760052242 nameplate, revision and installed-system documentation before use.
02	BP03 is not a unique global ABB key. Do not infer voltage, current, backplane function, compatibility or replacement from another BP03 designation.
03	De-energize and follow the site's approved electrical and process-safety procedure before disturbing hardware or field wiring.
04	Back up controller, network, I/O, addressing and configuration data before replacement or firmware work.
05	Verify every companion module, termination unit, cable, connector and power source from approved drawings.
06	Do not copy electrical, communication, mechanical or lifecycle values from a related model or successor.

Identity and release controls

Verification Status	Requested Label Only Manual And Nameplate Gate
---------------------	--

Official ABB sources

ABB Library – SPS03 and DCS power-hardware verification portal	https://library.abb.com/
--	---