

Schneider Electric AP4423

Schneider Electric AP4423 Installation and Verification Guide

rack-mount automatic transfer switch for two power sources

DOCUMENT SCOPE

Independent Apter Power manual compiled only from the cited Schneider Electric manufacturer sources. No product photograph is included.

Product / lookup identity	Schneider Electric AP4423
Reference number	AP4423
Document basis	Published Schneider Electric product records, PDFs, and manuals listed on page 3



Product page

<https://www.apterpower.com/Schneider-Electric/ap4423-rack-automatic-transfer-switch>

Apter Power contact

sales13@apterpower.com | +86 180 3023 5313

Workflow and system context

Schneider Electric AP4423 is rack-mount automatic transfer switch for two power sources. Identity boundary: Schneider Electric directly verifies AP4423 and its rack automatic-transfer-switch configuration.

- | | |
|----|--|
| 01 | rack-mount automatic transfer switch for two power sources |
| 02 | Use two suitable independent sources, the exact source cords and outlet loads permitted by Schneider documentation; verify voltage, current, grounding, rack environment and network settings before energizing. |

Published context and boundaries

- | | |
|----|--|
| 01 | Schneider Electric directly verifies AP4423 and its rack automatic-transfer-switch configuration. |
| 02 | Use two suitable independent sources, the exact source cords and outlet loads permitted by Schneider documentation; verify voltage, current, grounding, rack environment and network settings before energizing. |
| 03 | Use only the cited official manufacturer sources for technical interpretation. |

Verification and release checks

01	Verify the complete manufacturer nameplate, product code, revision and serial data before work.
02	Use two suitable independent sources, the exact source cords and outlet loads permitted by Schneider documentation; verify voltage, current, grounding, rack environment and network settings before energizing.
03	Isolate hazardous energy and follow the host equipment lockout and discharge procedure.
04	Use ESD controls and approved handling practices for exposed electronics and connectors.
05	Do not transfer ratings, terminals, functions or lifecycle claims from a sibling or successor product.
06	Inspect connectors, terminals, mounting features and protective earth provisions before installation.

Identity and release controls

Verification Status	Verified Exact Identity
---------------------	-------------------------

Official Schneider Electric sources

Schneider Electric AP4423 product page	https://www.se.com/pl/pl/product/AP4423/
Schneider Electric AP4423 Overview and Specifications	https://www.se.com/us/en/download/document/990-5839_EN/
Schneider Electric Rack ATS Installation and Quick Start Manual	https://www.se.com/us/en/download/document/990-5852_EN/