


MANUFACTURER-SOURCE TECHNICAL REFERENCE

General Electric DS200TBQCG1AAA

DS200TBQCG1AAA Label Verification Product Information Manual

General Electric DS200TBQCG1AAA Label Verification Official-Source Product Reference



DOCUMENT SCOPE

Independent Apter Power manual compiled only from the cited General Electric manufacturer sources. No product photograph is included.

Product / lookup identity	General Electric DS200TBQCG1AAA
Reference number	DS200TBQCG1AAA
Document basis	Published General Electric product records, PDFs, and manuals listed on page 3



Product page

<https://www.apterpower.com/General-Electric/ds200tbqcg1aaa>

Apter Power contact

sales13@apterpower.com | +86 180 3023 5313

Workflow and system context

General Electric DS200TBQCG1AAA is an evidence-bounded Mark V installed-base board. System role: The verified TBQC base family participates in the documented Mark V / Mark V LM migration interface to Mark VIe.

- | | |
|----|--|
| 01 | System Inputs: The verified TBQC base family participates in the documented Mark V / Mark V LM migration interface to Mark VIe. |
| 02 | Processing: GE Vernova states that Mark V is no longer produced and has limited refurbished, repair and exchange support; exact board revision and migration applicability remain site-specific. |

Published context and boundaries

- | | |
|----|---|
| 01 | Verify the complete DS200TBQCG1AAA label, Mark V rack position, cable and project drawings before use. |
| 02 | Do not transfer ratings, terminal assignments or compatibility from another TBQC suffix. The full DS200TBQCG1AAA label must match the installed unit. |
| 03 | Origin, HS code, dimensions and logistics weight remain unpublished without exact manufacturer model-level evidence. |

Verification and release checks

01	Verify the complete DS200TBQCG1AAA label, Mark V rack position, cable and project drawings before use.
02	Do not transfer ratings, terminal assignments or compatibility from another TBQC suffix. The full DS200TBQCG1AAA label must match the installed unit.
03	De-energize the equipment and follow the site's approved electrical and process-safety procedure before disturbing hardware or wiring.
04	Back up controller, network, I/O and configuration data before replacement, migration or firmware work.
05	Verify every companion module, cable, connector, termination and power source from approved drawings.
06	Do not copy electrical, communication, mechanical or lifecycle values from a related model, suffix or successor.

Identity and release controls

Verification Status	Verified Requested Label With Official Base Family Boundary
---------------------	---

Official General Electric sources

GE Vernova Controls Lifecycle Services	https://www.gevernova.com/gas-power/services/digital-and-controls/lifecycle-services
--	---