

CI526 3BSE006085R1

ISA-to-AF100 interface module

The CI526 3BSE006085R1 is an ABB ISA-to-AF100 interface module. It provides an engineering-station interface to the Advant Fieldbus 100 network.

Manufacturer	ABB / Elsasg Bailey
Complete model	CI526 3BSE006085R1
Product description	ISA-to-AF100 interface module
Prepared by	Apter Power
Document ID	AP-ABB-CI526 3BSE006085R1-PR-R1
Revision / issue	R1 / 2026-08-26

APTER POWER SALES TEAM

INDUSTRIAL AUTOMATION PRODUCT SUPPORT

Three interface paths, one controlled configuration.

WHATSAPP / PHONE +86 180 3023 5313
EMAIL sales13@apterpower.com
WEBSITE www.apterpower.com



SCAN FOR PRODUCT &
QUOTE

CI526 3BSE006085R1

1. Product overview and identity

The CI526 3BSE006085R1 is an ABB ISA-to-AF100 interface module. It provides an engineering-station interface to the Advant Fieldbus 100 network.

System function

Provides an engineering-station interface to the Advant Fieldbus 100 network.

Verified technical information

Parameter	Verified value
Manufacturer	ABB
Complete model	CI526 3BSE006085R1
Verified product description	ISA-to-AF100 interface module
System function	provides an engineering-station interface to the Advant Fieldbus 100 network
Direct field signals	See exact manufacturer manual and installed-system drawings
Revision / option status	Verify complete physical nameplate
Unpublished values	Not inferred

2. Integration and verification

Signals and data handled

Signal types and electrical ratings are defined by the cited manufacturer document and the installed-system configuration. Values not stated for this exact complete identifier are intentionally omitted.

Companion components

Use only the controller, rack, terminal unit, cable, sensor, actuator or power components explicitly documented for the installed ABB system and revision.

Common industrial applications

Industrial automation, process control, machinery, utilities or robotics installations using the named ABB product family; exact use depends on the approved system design.

Product precautions

- Match the complete model, order code, revision and physical construction before installation or replacement.
- Use only the electrical ratings, wiring and environmental limits stated in the applicable ABB document.
- Record the existing configuration and test every affected signal, communication path and safety function before release.

Manufacturer source PDFs

Manufacturer document	Direct PDF
ABB manufacturer document / product-family reference	Open PDF in a new window

Only information traceable to the cited ABB/Elsag Bailey documents is stated. Missing values are intentionally not inferred. Confirm the complete nameplate, revision, approvals, wiring and current manufacturer instructions before installation or replacement.