


MANUFACTURER-SOURCE TECHNICAL REFERENCE

Honeywell FC-IOCHAS-0001S

FC-IOCHAS-0001S Product Information Manual

non-redundant Safety Manager I/O chassis



DOCUMENT SCOPE

Independent Apter Power manual limited to verified identity evidence and any directly relevant Honeywell sources listed in this document. No product photograph is included.

Product / lookup identity	Honeywell FC-IOCHAS-0001S
Reference number	FC-IOCHAS-0001S
Document basis	Published Honeywell product records, PDFs, and manuals listed on page 3



Product page

<https://www.apterpower.com/Honeywell/fc-iochas-0001s>
Apter Power contact

sales13@apterpower.com | +86 180 3023 5313

Workflow and system context

Honeywell FC-IOCHAS-0001S is a coated chassis for non-redundant Safety Manager I/O modules. Use FC-IOCHAS-0001S only with the exact host, rack or chassis, terminal hardware, cable and project configuration specified for the installed system.

01	System Inputs: non-redundant Safety Manager I/O chassis
02	Processing: Use FC-IOCHAS-0001S only with the exact host, rack or chassis, terminal hardware, cable and project configuration specified for the installed system.

Published context and boundaries

01	Use FC-IOCHAS-0001S only with the exact host, rack or chassis, terminal hardware, cable and project configuration specified for the installed system.
02	Lifecycle evidence boundary: Use the cited model-level lifecycle statement where supplied.
03	Verify the complete Honeywell FC-IOCHAS-0001S physical label before use.

Verification and release checks

01	Verify the complete Honeywell FC-IOCHAS-0001S physical label before use.
02	Use FC-IOCHAS-0001S only with the exact host, rack or chassis, terminal hardware, cable and project configuration specified for the installed system.
03	Confirm the exact rack or chassis position, terminal assembly, cable, connector, power and project revision.
04	De-energize the equipment unless the exact hardware manual and site procedure explicitly permit energized service.
05	Back up controller, communication and I/O configuration before replacement or migration work.
06	Do not transfer electrical, communication or mechanical values from a related model or different suffix.

Identity and release controls

Verification Status	Verified Product Reference
---------------------	----------------------------

Official Honeywell sources

Honeywell System HINTS November 2020	https://process.honeywell.com/content/dam/process/en/documents/document-lists/doc_list_hints/2020/2020-November-System%20HINTS.pdf
--------------------------------------	---