

MANUFACTURER-SOURCE TECHNICAL REFERENCE

ABB DSCA160A DSCA160A

DSCA160A DSCA160A Verification Product Information Manual

ABB requested ABB legacy board identity reference product reference

DOCUMENT SCOPE

Independent Apter Power manual limited to verified identity evidence and any directly relevant ABB sources listed in this document. No product photograph is included.

Product / lookup identity	ABB DSCA160A DSCA160A
Reference number	DSCA160A DSCA160A
Document basis	Published ABB product records, PDFs, and manuals listed on page 3



Product page

<https://www.apterpower.com/ABB/dsca160a-identity-verification>
Apter Power contact

sales13@apterpower.com | +86 180 3023 5313

Workflow and system context

ABB DSCA160A is an evidence-bounded requested ABB legacy board identity reference. Compatibility boundary: Do not copy DSCA125A, DSCA160 or other communications-board parameters without the exact suffix and ABB manual.

01	System Inputs: requested ABB legacy board identity reference
02	Processing: Do not copy DSCA125A, DSCA160 or other communications-board parameters without the exact suffix and ABB manual.

Published context and boundaries

01	The requested DSCA160A identity is retained, but no directly relevant ABB-hosted model document was found.
02	Do not copy DSCA125A, DSCA160 or other communications-board parameters without the exact suffix and ABB manual.
03	Country of origin, HS code, dimensions and logistics weight remain unpublished without exact ABB model-level evidence.

Verification and release checks

01	Verify the complete ABB DSCA160A label and requested part number before use.
02	Do not copy DSCA125A, DSCA160 or other communications-board parameters without the exact suffix and ABB manual.
03	Confirm the exact host controller, rack position, terminal unit, cable, connector, firmware and project revision.
04	De-energize the equipment and follow the site's approved electrical and process-safety procedure before disturbing hardware or wiring.
05	Back up controller, communication and I/O configuration before replacement or migration work.
06	Do not transfer channels, ranges, voltage, current, communication, mechanical or lifecycle values from a sibling, predecessor or successor.

Identity and release controls

Verification Status	Requested Label Only
---------------------	----------------------

Official ABB sources

Source-link status	No directly relevant official manufacturer source link was found for this exact requested identity. Unrelated and third-party links are intentionally omitted.
--------------------	--