

MANUFACTURER-SOURCE TECHNICAL REFERENCE

Honeywell 621-1100RC

621-1100RC Product Information Manual

IPC 620 115 VAC/VDC discrete input module

DOCUMENT SCOPE

Apter Power product reference prepared from product-specific Honeywell technical information. Confirm the complete product identity and installed-system requirements before use. No product photograph is included.

Product / lookup identity	Honeywell 621-1100RC
Reference number	621-1100RC
Document basis	Product-specific Honeywell technical information



Product page

<https://www.apterpower.com/Honeywell/621-1100rc>

Apter Power contact

sales13@apterpower.com | +86 180 3023 5313

Workflow and system context

Honeywell 621-1100RC is an eight-point 115 VAC/VDC discrete input module for the IPC 620 I/O platform. Its primary hardware function is IPC 620 115 VAC/VDC discrete input module.

- | | |
|----|--|
| 01 | System Inputs: IPC 620 115 VAC/VDC discrete input module |
| 02 | Processing: Honeywell 621-1100RC is an eight-point 115 VAC/VDC discrete input module for the IPC 620 I/O platform. |

Published context and boundaries

- | | |
|----|--|
| 01 | Use 621-1100RC with the exact Honeywell host, companion hardware, terminal assembly and field wiring specified for the installed system. |
| 02 | Verify model 621-1100RC and part number 621-1100RC on the physical label before use. |
| 03 | Match every 621-1100RC connector, terminal, cable and companion assembly before moving field wiring. |



Verification and release checks

01	Verify model 621-1100RC and part number 621-1100RC on the physical label before use.
02	Use 621-1100RC with the exact Honeywell host, companion hardware, terminal assembly and field wiring specified for the installed system.
03	Match every 621-1100RC connector, terminal, cable and companion assembly before moving field wiring.
04	Back up the applicable controller, node, I/O or communication configuration before replacing 621-1100RC.
05	Isolate energy before handling 621-1100RC unless the applicable hardware procedure explicitly permits energized service.
06	Follow ESD controls and protect 621-1100RC connectors and printed-circuit assemblies during handling.

Identity and release controls

Verification Status	Product Reference
---------------------	-------------------