

MANUFACTURER-SOURCE TECHNICAL REFERENCE

Honeywell 620-0036 620-0036

620-0036 Product Information Manual

IPC 620-35 processor power supply

DOCUMENT SCOPE

Apter Power product reference prepared from product-specific Honeywell technical information. Confirm the complete product identity and installed-system requirements before use. No product photograph is included.

Product / lookup identity	Honeywell 620-0036 620-0036
Reference number	620-0036
Document basis	Product-specific Honeywell technical information

**Product page**<https://www.apterpower.com/Honeywell/620-0036>**Apter Power contact**

sales13@apterpower.com | +86 180 3023 5313

Workflow and system context

Honeywell 620-0036 is the processor power supply used with an IPC 620-35 controller assembly. Its primary hardware function is IPC 620-35 processor power supply.

01	System Inputs: IPC 620-35 processor power supply
02	Processing: Honeywell 620-0036 is the processor power supply used with an IPC 620-35 controller assembly.

Published context and boundaries

01	Use 620-0036 with the exact Honeywell host, companion hardware, terminal assembly and field wiring specified for the installed system.
02	Verify model 620-0036 and part number 620-0036 on the physical label before use.
03	Match every 620-0036 connector, terminal, cable and companion assembly before moving field wiring.

Verification and release checks

01	Verify model 620-0036 and part number 620-0036 on the physical label before use.
02	Use 620-0036 with the exact Honeywell host, companion hardware, terminal assembly and field wiring specified for the installed system.
03	Match every 620-0036 connector, terminal, cable and companion assembly before moving field wiring.
04	Back up the applicable controller, node, I/O or communication configuration before replacing 620-0036.
05	Isolate energy before handling 620-0036 unless the applicable hardware procedure explicitly permits energized service.
06	Follow ESD controls and protect 620-0036 connectors and printed-circuit assemblies during handling.

Identity and release controls

Verification Status	Product Reference
---------------------	-------------------