

MANUFACTURER-SOURCE TECHNICAL REFERENCE

Honeywell MC-TAOY22 51204172-175

MC-TAOY22 Product Information Manual

analog output field termination assembly

DOCUMENT SCOPE

Apter Power product reference prepared from product-specific Honeywell technical information. Confirm the complete product identity and installed-system requirements before use. No product photograph is included.

Product / lookup identity	Honeywell MC-TAOY22 51204172-175
Reference number	51204172-175
Document basis	Product-specific Honeywell technical information



Product page

<https://www.apterpower.com/Honeywell/mc-taoy22-51204172-175>
Apter Power contact

sales13@apterpower.com | +86 180 3023 5313

Workflow and system context

Honeywell MC-TAOY22 51204172-175 is an analog output field termination assembly for compatible Honeywell process I/O hardware. Its primary hardware function is analog output field termination assembly.

- | | |
|----|--|
| 01 | System Inputs: analog output field termination assembly |
| 02 | Processing: Honeywell MC-TAOY22 51204172-175 is an analog output field termination assembly for compatible Honeywell process I/O hardware. |

Published context and boundaries

- | | |
|----|---|
| 01 | Use MC-TAOY22 with the exact Honeywell host, companion hardware, terminal assembly and field wiring specified for the installed system. |
| 02 | Verify model MC-TAOY22 and part number 51204172-175 on the physical label before use. |
| 03 | Match every MC-TAOY22 connector, terminal, cable and companion assembly before moving field wiring. |

Verification and release checks

01	Verify model MC-TAOY22 and part number 51204172-175 on the physical label before use.
02	Use MC-TAOY22 with the exact Honeywell host, companion hardware, terminal assembly and field wiring specified for the installed system.
03	Match every MC-TAOY22 connector, terminal, cable and companion assembly before moving field wiring.
04	Back up the applicable controller, node, I/O or communication configuration before replacing MC-TAOY22.
05	Isolate energy before handling MC-TAOY22 unless the applicable hardware procedure explicitly permits energized service.
06	Follow ESD controls and protect MC-TAOY22 connectors and printed-circuit assemblies during handling.

Identity and release controls

Verification Status	Product Reference
---------------------	-------------------