

MANUFACTURER-SOURCE TECHNICAL REFERENCE

Honeywell 51304511-200

Product Information Manual

CE-compliant NIM modem I/O board

DOCUMENT SCOPE

Apter Power product reference prepared from product-specific Honeywell technical information. Confirm the complete product identity and installed-system requirements before use. No product photograph is included.

Product / lookup identity	Honeywell 51304511-200
Reference number	51304511-200
Document basis	Product-specific Honeywell technical information



Product page

<https://www.apterpower.com/Honeywell/51304511-200>

Apter Power contact

sales13@apterpower.com | +86 180 3023 5313

Workflow and system context

Honeywell 51304511-200 is a CE-compliant NIM modem I/O board used in the PNI I/O position of a TDC 3000 Network Interface Module. Its primary hardware function is CE-compliant NIM modem I/O board.

- | | |
|----|---|
| 01 | System Inputs: CE-compliant NIM modem I/O board |
| 02 | Processing: Honeywell 51304511-200 is a CE-compliant NIM modem I/O board used in the PNI I/O position of a TDC 3000 Network Interface Module. |

Published context and boundaries

- | | |
|----|--|
| 01 | Use 51304511-200 with the exact Honeywell host, companion hardware, terminal assembly and field wiring specified for the installed system. |
| 02 | Verify model 51304511-200 and part number 51304511-200 on the physical label before use. |
| 03 | Match every 51304511-200 connector, terminal, cable and companion assembly before moving field wiring. |



Verification and release checks

01	Verify model 51304511-200 and part number 51304511-200 on the physical label before use.
02	Use 51304511-200 with the exact Honeywell host, companion hardware, terminal assembly and field wiring specified for the installed system.
03	Match every 51304511-200 connector, terminal, cable and companion assembly before moving field wiring.
04	Back up the applicable controller, node, I/O or communication configuration before replacing 51304511-200.
05	Isolate energy before handling 51304511-200 unless the applicable hardware procedure explicitly permits energized service.
06	Follow ESD controls and protect 51304511-200 connectors and printed-circuit assemblies during handling.

Identity and release controls

Verification Status	Product Reference
---------------------	-------------------