

MANUFACTURER-SOURCE TECHNICAL REFERENCE

Bently Nevada 200155-02-CN

Installation Guide

low-frequency Trendmaster Pro accelerometer

DOCUMENT SCOPE

Apter Power product reference prepared from product-specific Bently Nevada technical information. Confirm the complete product identity and installed-system requirements before use. No product photograph is included.

Product / lookup identity	Bently Nevada 200155-02-CN
Reference number	200155-02-CN
Document basis	Bently Nevada technical documents listed on page 3



Product page

<https://www.apterpower.com/Bently-Nevada/200155-02-cn>

Apter Power contact

sales13@apterpower.com | +86 180 3023 5313

Workflow and system context

Bently Nevada 200155-02-CN is a low-frequency Trendmaster Pro accelerometer supplied with a 3/8-24 to 3/8-24 UNF 1-3/8 in hex plate stud. Use it only in the matched Bently Nevada machinery-monitoring installation and verify the complete product code, associated hardware, mounting and wiring before service.

- | | |
|----|---|
| 01 | System Inputs: low-frequency Trendmaster Pro accelerometer |
| 02 | Processing: Bently Nevada 200155-02-CN is a low-frequency Trendmaster Pro accelerometer supplied with a 3/8-24 to 3/8-24 UNF 1-3/8 in hex plate stud. |

Published context and boundaries

- | | |
|----|--|
| 01 | Confirm the mounting stud, cable interface, power source and installed Trendmaster system before installation. |
| 02 | Verify model 200155-02-CN and the complete order code on the physical label before use. |
| 03 | Match every 200155-02-CN connector, terminal, cable and companion assembly before moving field wiring. |

Verification and release checks

01	Verify model 200155-02-CN and the complete order code on the physical label before use.
02	Confirm the mounting stud, cable interface, power source and installed Trendmaster system before installation.
03	Match every 200155-02-CN connector, terminal, cable and companion assembly before moving field wiring.
04	Back up the applicable controller, monitor, HMI or I/O configuration before replacing 200155-02-CN.
05	Isolate energy and follow the approved site safety procedure before handling 200155-02-CN.
06	Follow ESD controls and protect 200155-02-CN connectors and printed-circuit assemblies during handling.

Identity and release controls

Verification Status	Verified Product Reference
---------------------	----------------------------

Official Bently Nevada sources

200150, 200155 and 200157 Accelerometers Datasheet	https://dam.bakerhughes.com/m/205aecc925d18534/original/200150-200155-and-200157-Accelerometers-Datasheet-164986-pdf.pdf
--	---